


—
OPTIONS FOR ABB DRIVES

FPBA-01 PROFIBUS DP adapter module

User's manual



List of related documents

See section [Related documents](#) on page 19.

You can find manuals and other product documents in PDF format on the Internet. See section Document library on the Internet on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

The code below opens an online listing of the manuals applicable to the product:



[FPBA-01 manual](#)



[Fieldbus connectivity webpage](#)

FPBA-01 PROFIBUS DP adapter module

User's manual

Table of contents



1. Safety instructions



4. Mechanical installation



5. Electrical installation



6. Start-up



3AFE68573271 Rev H

EN

EFFECTIVE: 2024-06-25

Table of contents

1. Safety instructions

Contents of this chapter	11
Use of warnings	11
Safety in installation and maintenance	12

2. Introduction to the manual

Contents of this chapter	13
Applicability	13
Compatibility	13
Target audience	14
Purpose of the manual	14
Cybersecurity disclaimer	14
Before you start	14
Terms and abbreviations	15
General terms and abbreviations	15
PROFIBUS terms	16
PROFIBUS abbreviations	17
Related documents	19

3. Overview of the PROFIBUS network and the FPBA-01 module

Contents of this chapter	21
PROFIBUS network	21
Example topology of the PROFIBUS link	23
FPBA-01 PROFIBUS DP adapter module	24
Layout of the adapter module	25

4. Mechanical installation

Contents of this chapter	27
Necessary tools and instructions	27
Unpacking and examining the delivery	27
Before you start	28

Installing option modules	28
---------------------------------	----

5. Electrical installation

Contents of this chapter	31
Necessary tools and instructions	31
General cabling instructions	31
Connecting the module to the PROFIBUS network	32
Switching on the bus termination	34

6. Start-up

Contents of this chapter	35
Drive configuration	36
PROFIBUS connection configuration	36
Data transfer rates supported	37
Emulation modes	37
RPBA-01, NPBA-02 and NPBA-12 modes	37
VIK-NAMUR mode	38
FPBA-01 configuration parameters – group A (group 1)	
39	
FPBA-01 configuration parameters – group B (group 2)	
47	
FPBA-01 configuration parameters – group C (group 3)	
49	
Virtual address allocation with ACSM1	51
Control locations	52
Starting up ACS355 drives	53
Parameter setting examples – ACS355	54
Speed control using the PROFIdrive communication	
profile with PPO Type 2	54
Speed and torque control using the ABB Drives commu-	
nication profile with PPO Type 4	57
Starting up ACSM1 drives	61
Parameter setting examples – ACSM1	62
Speed control using the PROFIdrive communication	
profile with PPO Type 2	62
Position control using the PROFIdrive communication	

profile with PPO Type 4	65
Speed and torque control using the ABB Drives communication profile with PPO Type 4	70
Starting up ACS380 drives	73
Setting up the drive for fieldbus control manually	74
Starting up ACS850 and ACQ810 drives	76
Parameter setting examples – ACS850 and ACQ810	78
Speed control using the PROFIdrive communication profile with PPO Type 2	78
Starting up ACS880 and ACS880-M04 drives	81
Parameter setting examples – ACS880 and ACS880-M04	82
Speed control using the PROFIdrive communication profile with PPO Type 2	82
Configuring the master station	85
Downloading the GSD file	85
Configuring an ABB AC500 PLC	86
Configuring a Siemens SIMATIC S7 PLC	91
Configuring a Siemens S7 PLC with TIA Portal V13	97
Cyclic data handling	101

7. Communication profiles

Contents of this chapter	103
Communication profiles	103
PROFIdrive communication profile	105
Control word and Status word	105
Control word contents	105
Status word contents	109
State machine for all operating modes	111
State machine for positioning mode	112
References	113
References in speed control mode	113
References in positioning mode (ACSM1 only)	113
Actual values	114
Actual values in speed control mode	114
Actual values in positioning mode (ACSM1 only)	114

ABB Drives communication profile	115
Control word and Status word	115
Control word contents	115
Status word contents	118
State machine	120
References	121
Scaling	121
Actual values	122
Scaling	122
PROFIdrive v4.2 communication profile	123
Supported drives	123
Control word and Status word	123
Control word contents	123
Status word contents	125
State machine	127
References	129
References in speed control mode	129
Actual values	129
Actual values in speed control mode	130

8. Communication protocol

Contents of this chapter	131
PROFIBUS DP	131
Service access points (SAPs)	132
Communication start-up	132
PROFIBUS SD2 telegram for Default SAP (0) and SAP 58-62.	133
Default SAP (SAP 0) (Data_Exch)	134
SAP 58 (Global_Control)	135
SAP 60 (Slave_Diag)	136
SAP 61 (Set_Prm)	140
SAP 62 (Chk_Cfg)	146
Other SAPs for DP-V1 communication	148
Cyclical message types	149
PPO types	149
Standard telegram (ST) types (DP-V1)	150

Parameter handling in cyclic communication (DP)	151
Parameter data transfer examples (DP-V0)	156
Example 1: Reading a drive parameter (or data set)	156
Example 2: Writing a drive parameter (or data set).	158
Example 3: Reading a PROFIdrive parameter (word)	160
Example 4: Writing a PROFIdrive parameter (word)	161
Example 5: Reading a PROFIdrive parameter (array)	162
Example 6: Configuring the process data written to the drive	163
Example 7: Configuring the process data read from the drive	164
DP-V1 read/write request sequence	165
PROFIBUS SD2 telegram for SAP 51	167
Parameter data transfer examples (DP-V1)	176
Example 1a: Reading a drive parameter (array element)	177
Example 1b: Reading 3 drive parameters (multi-param- eter)	179
Example 2a: Writing a drive parameter (one array ele- ment)	182
Example 2b: Writing 2 drive parameters (multi-parame- ter).....	184
Example 3: Reading a PROFIdrive parameter	186
Example 4: Configuring the process data written to the drive	187
Example 5: Determining the source of process data read from the drive.....	190

9. Diagnostics

Contents of this chapter	193
LED indications	193

10. Technical data

Contents of this chapter	195
FPBA-01	195
PROFIBUS link	197

License information for 3rd party components 198

11. Appendix A – PROFIdrive parameters

Contents of this chapter201
PROFIdrive parameters201

12. Appendix B – I&M records

Contents of this chapter213
I&M records213
 Call-REQ-PDU telegram for read/write access to I&M re-
 cords214
 Response structure for I&M0 (Read-only)215
 Response structure for I&M1 (Read/Write)216
 Response structure for I&M2 (Read/Write)216

Further information

1

Safety instructions

Contents of this chapter

The chapter describes the warning symbols used in this manual and refers to the safety instructions which you must obey when you install or connect an option module. If you ignore the safety instructions, injury, death or damage can occur. Read this chapter before you start the installation.

Use of warnings

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. Notes draw attention to a particular condition or fact, or give information on a subject.

The manual uses these warning symbols:



Electricity warning tells you about hazards from electricity which can cause injury or death, or damage to the equipment.



General warning tells you about conditions, other than those caused by electricity, which can cause injury or death, or damage to the equipment.

Safety in installation and maintenance

These instructions are for all who install or connect an optional module to a drive, converter or inverter and need to open its front cover or door to do the work.



WARNING! Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

Introduction to the manual

Contents of this chapter

This chapter introduces this manual.

Applicability

This manual applies to the FPBA-01 PROFIBUS DP adapter module, SW version 3.10 or later.

Compatibility

The FPBA-01 PROFIBUS DP adapter module is compatible with the following drives: ACSM1, ACS355, ACS380, ACS480, ACS580, ACH580, ACQ580, ACS850, ACQ810, ACS880, ACS880-M04, etc.

The FPBA-01 PROFIBUS DP adapter module is compatible with all master stations that support the PROFIBUS DP-V0 and DP-V1 protocols.

Note: The adapter module is compatible with more drives that may not be listed here. For details of compatibility, check the drive's firmware manual.

Target audience

The reader is expected to have a basic knowledge of the fieldbus interface, electrical fundamentals, electrical wiring practices and how to operate the drive.

Purpose of the manual

The manual provides information on installing, commissioning and using an FPBA-01 PROFIBUS DP adapter module.

Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

Before you start

It is assumed that the drive is installed and ready to operate before you start the installation of the adapter module.

In addition to conventional installation tools, have the drive manuals available during the installation as they contain important information not included in this manual. The drive manuals are referred to at various points of this manual.

Terms and abbreviations

■ General terms and abbreviations

Term / Abbreviation	Explanation
Communication module	Communication module is a name for a device (eg, a fieldbus adapter) through which the drive is connected to an external communication network (eg, a fieldbus). The communication with the module is activated with a drive parameter.
Command word	See Control word.
Control word	16-bit word from master to slave with bit-coded control signals (sometimes called the Command word).
FPBA-01 PROFIBUS DP adapter module	One of the optional fieldbus adapter modules available for ABB drives. FPBA-01 is a device through which an ABB drive is connected to a PROFIBUS network.
Parameter	Operating instruction for the drive. Parameters can be read and programmed with the drive control panel, drive PC tools or through the adapter module.
PLC	Programmable logic controller
Profile	Adaptation of the protocol for certain application field, for example, drives. In this manual, drive-internal profiles (eg, DCU or FBA) are called native profiles.
Status word	16-bit word from slave to master with bit-coded status messages

■ PROFIBUS terms

Term	Explanation
Acyclic communication	Communication in which messages are sent only once on request
Array	Parameter consisting of data fields of equal data type
Broadcast	Non-acknowledged message from master to all bus participants (compare Multicast)
Cyclic communication	Communication in which parameter/process data objects are sent cyclically at predefined intervals
Drivecast	Broadcast and Multicast, a special message frame for drives
Fault	Event that leads to tripping of the device
GSD file	ASCII-format device description file in a specified form. Each different slave type on the PROFIBUS network needs to have its own GSD file.
Index	Access reference for objects in PROFIBUS
Master	Control system with bus initiative. In the PROFIBUS terminology, master stations are also called active stations.
Multicast	Non-acknowledged message from master to one group of bus participants (compare Broadcast)
Name	Symbolic name of a parameter
Parameter	Value that can be accessed as an object, eg, variable, constant, signal
Parameter number	Parameter address
Parameter/Process	Special object that contains parameter and process
Data object	Special object that contains parameter and process data

Term	Explanation
Process data	Data that contains Control word and reference value or Status word and actual value. May also contain other (user-definable) control information.
Request label	Coded information specifying the required service for the parameter part sent from master to slave
Response label	Coded information specifying the required service for the parameter part sent from slave to master
Slave	Passive bus participant. In the PROFIBUS terminology, slave stations (or slaves) are also called passive stations. Also referred to as node.
Warning	Signal caused by an existing alarm which does not lead to tripping of the device

■ PROFIBUS abbreviations

The text in *italics* is the original German term.

Abbreviation	Explanation
ACT	Actual value <i>Istwert</i>
AK	Request label/Response label <i>Auftragskennung/Antwortkennung</i>
DP	Decentralised Periphery <i>Dezentrale Peripherie</i>
DP-V0	PROFIBUS DP extension to the EN 50170 standard, providing the basic functionality of DP, including cyclic data exchange
DP-V1	PROFIBUS DP extension to the EN 50170 standard, including, eg, acyclic data exchange
FMS	Fieldbus Message Specification
ISW	See ACT.

Abbreviation	Explanation
PA	Process Automation Prozessautomatisierung
PD	Process data <i>Prozessdaten</i>
PKE	Parameter identification <i>Parameter-Kennung</i>
PKW	Parameter identification value <i>Parameter-Kennung-Wert</i>
PNU	Parameter number Parameternummer
PPO	Parameter/Process data object <i>Parameter-/Prozessdaten-Objekt</i>
PWE	Parameter value Parameter-Wert
PZD	See PD.
PZDO	Process data object <i>Prozessdatenobjekt</i>
SAP	Service access point
SOW	Reference <i>Sollwert</i>
SPM	Request signal <i>Spontanmeldung</i>
STW	Control word <i>Steuerwort</i>
ZSW	Status word <i>Zustandswort</i>

Related documents

You can find manuals on the Internet. See below for the relevant link. For more documentation, go to www.abb.com/drives/documents.

Drive user's manuals	Code (English)
ACS355 drives (0.37...22 kW, 0.5...30 hp) user's manual	3AUA0000066143
Drive hardware manuals and guides	
ACSM1 manuals	00578051
ACH580-01 manuals	9AKK10103A0587
ACH580-04 manuals	9AKK106930A9059
ACH580-07 manuals	9AKK106930A5241
ACQ580-01 manuals	9AKK106713A2709
ACQ580-04 manuals	9AKK106930A9053
ACQ580-07 manuals	9AKK106930A3150
ACS580-01 manuals	9AKK105713A8085
ACS580-04 manual	9AKK106930A9060
ACS580-07 (250 to 500 kW) manuals	9AKK106713A0278
ACS580-07 (75 to 250 kW) manuals	9AKK106930A5239
ACS850-04 manuals	00592009
ACQ810 manuals	00598718
ACS880-01 manuals	9AKK105408A7004
ACS880-04 manuals	9AKK105713A4819
ACS880-07 manuals (45 to 710 kW)	9AKK105408A8149
ACS880-07 (560 to 2800 kW)	9AKK105713A6663
ACS880-17 (132 to 355 kW)	9AKK106930A3466
ACS880-17 (160 to 3200 kW)	9AKK106354A1499
ACS880-37 (132 to 355 kW)	9AKK106930A3467
ACS880-37 (160 to 3200 kW)	9AKK106354A1500
Cybersecurity for ABB drives Technical guide	3AXD10000492137
Option manuals and guides	
FPBA-01 PROFIBUS DP adapter module user's manual	3AFE68573271

For manuals not available in ABB Library, contact your local ABB representative.

3

Overview of the PROFIBUS network and the FPBA-01 module

Contents of this chapter

This chapter contains a short description of the PROFIBUS network and the FPBA-01 PROFIBUS DP adapter module.

PROFIBUS network

PROFIBUS is an open serial communication standard that enables data exchange between all kinds of automation components. There are three main variations of PROFIBUS:

- PROFIBUS FMS (Fieldbus Message Specification)
- PROFIBUS DP (Decentralised Periphery)
- PROFIBUS PA (Process Automation).


The physical transmission medium of the bus is a twisted pair cable (according to the RS-485 standard). The maximum length of the bus cable is 100 to 1200 meters, depending on the selected transmission rate (see chapter [Technical data](#)). Up to 32 nodes can be connected to the same PROFIBUS network segment without the use of repeaters. With repeaters, it is possible to connect 126 nodes (including repeaters and a master station) to the network.

In PROFIBUS communication, the master station – usually a programmable logic controller (PLC) – polls the nodes which respond and take the actions requested by the master. It is also possible to send a command to several nodes at the same broadcast; in this case the nodes do not send a response message to the master.

The PROFIBUS protocol family is specified in the IEC 61158 standard. The communication with a drive is defined in *PROFIdrive-PROFILE – The PROFIBUS Profile for Adjustable Speed Drives*. For further information on PROFIBUS, refer to the above-mentioned standard.

■ **Example topology of the PROFIBUS link**

The figure below shows an example of an allowable topology of the PROFIBUS link.



FPBA-01 PROFIBUS DP adapter module

The FPBA-01 PROFIBUS DP adapter module is an optional device for ABB drives which enables the connection of the drive to a PROFIBUS network. The drive is considered a slave on the PROFIBUS network.

Through the adapter module you can:

- give control commands to the drive (for example, Start, Stop, Run enable)
- feed a motor speed or torque reference to the drive
- give a process actual value or a process reference to the PID controller of the drive
- read status information and actual values from the drive
- change drive parameter values
- reset a drive fault.


Note: PROFIdrive v4.2 cannot access the drive parameters.

The PROFIBUS commands and services supported by the adapter module are described in chapter [Communication protocol](#) on page 131. Refer to the user documentation of the drive as to which commands are supported by the drive.

The adapter module is mounted into an option slot on the motor control unit of the drive. See the drive manuals for module placement options.

■ **Layout of the adapter module**

This figure shows the layout of FPBA-01.



Mechanical installation

Contents of this chapter

This chapter contains a delivery checklist and instructions on installing the module.

Necessary tools and instructions

You will need a Torx TX10 screwdriver to secure the FPBA-01 adapter module to the drive. See also the applicable drive hardware manual.

Unpacking and examining the delivery

1. Open the option package.
2. Make sure that the package contains:
 - PROFIBUS DP adapter module, type FPBA-01
 - this manual.
3. Make sure that there are no signs of damage.

Before you start

The adapter module has a specific position in the drive. Plastic pins, a lock and one screw to hold the adapter module in place. The screw also makes an electrical connection between the module and drive frame for cable shield grounding.

When the adapter module is installed, it makes the signal and power connection to the drive through a 20-pin connector.

Installing option modules





WARNING! Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive.
2. De-energize the drive system: Do the steps given in the safety instructions of the drive. Refer to the drive hardware manual.
3. Get access to the drive control unit.
4. Pull out the lock on the module (a).
5. Install the module to a free option module slot on the control unit.
6. Push in the lock on the module (a).
7. Torque the grounding screw (b) to 0.8 N·m (7 lbf·in)

Note: The screw tightens the connections and grounds the module. It is necessary for fulfilling the EMC requirements and for correct operation of the module.



WARNING! Do not use excessive force, or leave the screw too loose. Over-tightening can damage the screw or module. A loose screw decreases the EMC performance, and can even cause an operation failure.



If you need to remove the adapter module after it has been installed into the drive, use a suitable tool (e.g. small pliers) to carefully pull out the lock.

5

Electrical installation

Contents of this chapter

This chapter contains:

- general cabling instructions
- instructions on connecting the module to the PROFIBUS DP network
- instructions on switching on the bus termination.

Necessary tools and instructions

See the applicable drive hardware manual.


General cabling instructions

- Arrange the bus cables as far away from the motor cables as possible.
 - Avoid parallel runs.
 - Use grommets at cable entries.
-

Connecting the module to the PROFIBUS network

Connect the bus cable to connector X1 on the adapter module.

The connector pin allocation described below follows the PROFIBUS standard.




X1		Description
1	SHLD	Alternate cable shield connection. Connected to connector housing.
2		Not used
3	B	Data positive (Conductor 1 in twisted pair)
4	RTS ¹⁾	Request to send
5	GND_B	Isolated ground
6	+5V_B ²⁾	Isolated 5 V DC voltage supply (30 mA max.)
7		Not used
8	A	Data negative (Conductor 2 in twisted pair)
9		Not used
Housing	SHLD	PROFIBUS cable shield. Internally connected to GND_B via an RC filter and directly to CH_GND (chassis).

¹⁾ RTS is used in some equipment to determine the direction of transmission. In typical applications, only the line A, line B and shield are used.

²⁾ +5V_B and GND_B are used for bus termination.

ABB recommends to use a PROFIBUS-approved D-SUB 9 connector. These connectors have a built-in termination network and inductors for station capacitance compensation.


Connect the cable to the D-SUB connector as follows:



Switching on the bus termination

Bus termination is required to prevent signal reflections from the bus cable ends. The adapter module is not equipped with internal bus termination. Therefore, the D-SUB connectors at the first and last modules of the bus must have built-on termination switched on as shown in the diagram below.

The adapter module is able to supply power for an active-type termination circuitry (30 mA max.).



Note: Further information on PROFIBUS wiring is available from the publication *PROFIBUS RS 485-IS User and Installation Guideline* (www.profibus.com, order no. 2.262).

Start-up

Contents of this chapter

This chapter contains:

- information on configuring the drive for operation with the adapter module
 - drive-specific instructions on starting up the drive with the adapter module
 - examples of configuring the master station for communication with the adapter module.
-

Drive configuration

The following information applies to all drive types compatible with the adapter module, unless otherwise stated.

■ PROFIBUS connection configuration

After the adapter module is mechanically and electrically installed according to the instructions in chapters [Mechanical installation](#) and [Electrical installation](#), prepare the drive for communication with the module.

The detailed procedure of activating the module for PROFIBUS DP communication with the drive depends on the drive type. Normally, a parameter must be adjusted to activate the communication. See the drive-specific start-up procedures starting on page [53](#).

Once communication between the drive and the adapter module has been established, several configuration parameters are copied to the drive. These parameters are shown in the tables below and must be checked first and adjusted where necessary.

Note:

- Not all drives display descriptive names of the configuration parameters.
 - The new settings take effect only when the adapter module is powered up the next time or when the fieldbus adapter refresh parameter is activated.
 - Make sure the proper operation of the adapter module with the drive by also setting the extended Parameter Data (see [SAP 61 \(Set_Prm\)](#) on page [140](#)).
-

Data transfer rates supported

The FPBA-01 module supports the following PROFIBUS communication speeds: 9.6 kbit/s, 19.2 kbit/s, 45.45 kbit/s, 93.75 kbit/s, 187.5 kbit/s, 500 kbit/s, 1.5 Mbit/s, 3 Mbit/s, 6 Mbit/s, 12 Mbit/s.

The module automatically detects the communication speed and telegram type used.

■ Emulation modes

FPBA-01 supports emulation modes for RPBA-01, NPBA-02, NPBA-12 and VIK-NAMUR.

Emulation modes change the FPBA-01 identification information so that FPBA-01 accepts connection from PLC configuration made for RPBA-01, NPBA-02, NPBA-12 or VIK-NAMUR.

Emulation mode can be used in these conditions:

- when replacing an older drive
- where the PLC program cannot be changed
- when using ACS880 as a VIK-NAMUR drive.

RPBA-01, NPBA-02 and NPBA-12 modes

Cyclic process data is handled based on profile selection. Control word, status word, references and actuals can be used normally according to the configured profile.

PROFIdrive parameter handling in cyclic data (PKW DP-V0) is emulated. The parameter addresses can be modified to convert the request to drive parameter index similarly as in the emulated modules.

Note: Emulation mode only emulates parameter addresses. The emulated parameters need to be made on the drive side with application programming tools.

VIK-NAMUR mode

The VIK-NAMUR mode can be used in combination with ACS880 NAMUR application. With this mode, FPBA-01 acts in the transparent mode and the drive application provides cyclic data content for Standard telegram 20.

Use this mode with the generic VIK-NAMUR GSD file (*pd013aa0.gsd*).

Note: In NPBA-x2 and VIK-NAMUR emulation mode the cut-off timeout is constantly 30ms.

FPBA-01 configuration parameters – group A (group 1)

Note: The actual parameter group number depends on the drive type. Group A (group 1) corresponds to:

- parameter group 51 in ACSM1, ACS355, ACS380, ACS580, ACS850 and ACQ810
- parameter group 51 in ACS880 and ACS880-M04 if the adapter is installed as fieldbus adapter A or group 54 if the adapter is installed as fieldbus adapter B.

No.	Name/Value	Description	Default
01	FBA type	Read-only. Shows the fieldbus adapter type as detected by the drive. The value cannot be adjusted by the user. If the value is 0 = None, the communication between the drive and the module has not been established.	1 = Profibus_DP
02	Node address	Each device on the PROFIBUS network must have a unique node number. This parameter defines a node number for the drive the module is connected to. Recommended node numbers are 3 to 125 inclusive.	3
	0...126	Node number	
03	Baud rate	Read-only. Indicates the detected communication speed in kbit/s. 1) Default value is 0 if there is no connection.	1500 ¹⁾
	12000	12 Mbit/s	
	6000	6 Mbit/s	
	3000	3 Mbit/s	
	1500	1.5 Mbit/s	
	500	500 kbit/s	

40 Start-up

No.	Name/Value	Description	Default
	187	187.5 kbit/s	
	93	93.75 kbit/s	
	45	45.45 kbit/s	
	19	19.2 kbit/s	
	9	9.6 kbit/s	
04	MSG type	Read-only. Indicates the telegram type selected for PROFIBUS communication. The adapter module automatically detects the telegram type used. For more information on the supported PPO message types, see section PPO types on page 149. If standard telegrams (ST) are used, parameter 05 Profile is automatically set.	1 = PPO1
	1 = PPO1	PPO1 selected	
	2 = PPO2	PPO2 selected	
	3 = PPO3	PPO3 selected	
	4 = PPO4	PPO4 selected	
	5 = PPO5	PPO5 selected	
	6 = PPO6	PPO6 selected	
	7 = ST1	ST1 selected	
	8 = ST2	ST2 selected. Only supported with ACSM1.	
	9 = PPO7	PPO7 selected	
	10 = PPO8	PPO8 selected	
	20 = ST20	Standard telegram 20. Visible only in VIK-NAMUR emulation mode.	

No.	Name/Value	Description	Default
05	Profile	Selects the communication profile used. For more information on the communication profiles, see chapter Communication profiles .	1 = ABB drives
	0 = PROFIdrive	PROFIdrive profile selected. See also Virtual address allocation with ACSM1 on page 51.	
	1 = ABB DRIVES	ABB Drives profile selected	
	2 = Trans16	Transparent 16 profile selected	
	3 = Trans32	Transparent 32 profile selected. Not supported with ACS355.	
	4 = PROFIdrive P	PROFIdrive positioning mode selected. Only supported with ACSM1. See also Virtual address allocation with ACSM1 on page 51.	
	5 = PROFIdrive v4.2	PROFIdrive v4.2 profile selected.	

No. Name/Value	Description	Default
06 T16 scale	Defines the reference multiplier/actual value divisor for the adapter module. Note: The parameter is effective only when • Transparent 16 profile is selected • drive is using the native communication profile (for example, DCU or FBA) • a 16-bit transparent Reference 1/Actual value 1 is used. For ACS880, ACS380, ACS580 and ACS480, bus reference is multiplied by (T16 scale + 1). For example, value 0 will be 1 = 1 (the value 1 from PLC will be 1.00 in the drive), the value 99 will be 1 = 100.00. With an ACS355 drive, the speed reference from the PLC is multiplied by the value of this parameter plus one. For example, if the parameter has a value of 99 and a reference of 1000 is given by the master, the reference will be multiplied by 99 + 1 = 100 and forwarded to the drive as 100000. According to the DCU profile, this value is interpreted as a reference of 100 rpm in the drive. With ACSM1, ACS850 and ACQ810, setting this parameter to 65535 provides the approximation of 1 ≈ 1 rpm.	99
0...65535	Reference multiplier/actual value divisor	

No.	Name/Value	Description	Default
07	Emul mode	Enables the emulation mode for the drive. When the mode is enabled, it is possible to replace a drive using modules RPBA-01, NPBA-02 or NPBA-12 in the PROFIBUS network with a drive using the FPBA-01 module, without modifying the PLC hardware configuration. The VIK-NAMUR mode enables the use of ACS880 with the FPBA-01 module as a VIK-NAMUR device. See also Emulation modes on page 37.	0 = Disabled
	0 = Disabled	Emulation mode is disabled.	
	1 = RPBA-01	RPBA-01 emulation mode is enabled.	
	2 = NPBA-02	NPBA-02 emulation mode is enabled.	
	3 = NPBA-12	NPBA-12 emulation mode is enabled.	
	4 = VIK-NAMUR	VIK-NAMUR emulation mode is enabled.	
08	Map selection	Selects the resolution of parameter used for PZD mapping through PROFIdrive parameters 915 and 916.	0 = 32 bit
	0 = 32 bit	32 bit scaling	
	1 = 16 bit	16 bit scaling	
09	Module info	Indicates the status of mapping configuration.	
	0 = OK		
	1 = MAP_ERR_LAST	32 bit parameter is mapped in the last PZD place	
	2 = CFG_ERR_PPO	Wrong PPO/ST type (data size) code sent by PLC	

No.	Name/Value	Description	Default
	3 = MAP_ERR_WRONG_IDX	Wrong mapping index (e.g. index of PZD 10) is used when PPO type 2 is in use	
	4 = MAP_ERR_IN	Parameter number or virtual index number is not supported for input mapping	
	5 = MAP_ERR_OUT	Parameter number or virtual index number is not supported for output mapping	
	6 = MAP_ERR_SEND	Internal mapping error	
10 ... 26	Reserved	These parameters are not used by the adapter module.	N/A
27	FBA par refresh	Validates any changed adapter module configuration parameter settings. After refreshing, the value reverts automatically to 0 = Done . Note: This parameter cannot be changed while the drive is running.	0 = Done
	0 = Done	Refreshing done	
	1 = Refresh	Refreshing	

No.	Name/Value	Description	Default
28	FBA par table ver	Read-only. Displays the parameter table revision of the fieldbus adapter module mapping file stored in the memory of the drive. In format xyz , where x = major revision number y = minor revision number z = correction number OR in format axyz , where a = major revision number xy = minor revision number z = correction number or letter. OR in format axyz , where ax = major table revision number yz = minor table revision number.	N/A
		Parameter table revision	
29	FBA drive type code	Read-only. Displays the drive type code of the fieldbus adapter module mapping file stored in the memory of the drive.	N/A
		Drive type code of the fieldbus adapter module mapping file	
30	FBA mapping file ver	Read-only. Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format.	N/A
		Mapping file revision	
31	D2FBA comm status	Read-only. Displays the status of the fieldbus adapter module communication. Note: The value names may vary by drive.	0 = Idle OR 4 = Off-line
	0 = Idle/Not configured	Adapter is not configured.	

No.	Name/Value	Description	Default
	1 = Exec.init/ Initializing	Adapter is initializing.	
	2 = Time out	A timeout has occurred in the communication between the adapter and the drive.	
	3 = Conf.err/ Configuration error	Adapter configuration error: The major or minor revision code of the common program revision in the fieldbus adapter module is not the revision required by the module or mapping file upload has failed more than three times.	
	4 = Off-line	Adapter is off-line.	
	5 = On-line	Adapter is on-line.	
	6 = Reset	Adapter is performing a hardware reset.	
32	FBA A comm SW ver	Read-only. Displays firmware patch and build number of the adapter module in format xxyy , where: xx = patch number yy = build number. Example: C80D ≥ 200.13 or 0 ≥ 0.0	0 hex
	0...0xFFFF	Firmware patch and build number of the adapter module.	
33	FBA appl SW ver	Read-only. Displays the firmware version of the adapter module in format xxyy , where: xx = major revision number xy = minor revision number. Example: 0310h = 3.10 Version number is in the form: <major>.<minor>.<patch>.<build> Example: 3.10.200.3 or 3.10.0.0	0 hex
	0...0xFFFF	Firmware version of the adapter module.	

FPBA-01 configuration parameters – group B (group 2)

Note: The actual parameter group number depends on the drive type. Group B (group 2) corresponds to:

- parameter group 55 in ACS355
- parameter group 53 in ACSM1, ACS380, ACS580, ACS850, ACQ580, and ACQ810
- parameter group 53 in ACS880 and ACS880-M04 if the adapter is installed as fieldbus adapter A or group 56 if the adapter is installed as fieldbus adapter B.

No. ¹⁾	Name/Value	Description	Default						
01	FBA data out 1 (master to drive)	Selects the resolution of control word (16 bit or 32 bit) received by the drive.	1 or 11 ²⁾						
	1 = CW 16bit	Control word (16 bits)							
	11 = CW 32bit	Control word (32 bits)							
02	FBA data out 2	Selects data word 1 received by the drive over the PROFIBUS network. The content is defined by a decimal number in the range of 0 to 9999 as follows: <table><tr><td>0</td><td>Not used</td></tr><tr><td>1...99</td><td>Virtual address area of drive control</td></tr><tr><td>101...9999</td><td>Parameter area of the drive</td></tr></table> See also Virtual address allocation with ACSM1 on page 51.	0	Not used	1...99	Virtual address area of drive control	101...9999	Parameter area of the drive	0 or 24 ⁴⁾
0	Not used								
1...99	Virtual address area of drive control								
101...9999	Parameter area of the drive								
	0 = None	Not used							
	1 = CW 16bit	Control word (16 bits) ³⁾							
	2 = Ref1 16bit	Reference REF1 (16 bits) ³⁾							
	3 = Ref2 16bit	Reference REF2 (16 bits) ³⁾							
	11 = CW 32bit	Control word (32 bits)							
	12 = Ref1 32bit	Reference REF1 (32 bits)							

No. ¹⁾	Name/Value	Description	Default
	13 = Ref2 32bit	Reference REF2 (32 bits)	
	21 = CW2 16bit	Control word 2 (16 bits)	
	101...9999	Parameter index with format xxyy , where • xx is the parameter group number (1...99) • yy is the parameter number index within that group (01...99).	
	Other	Path to parameter area selection.	
03 ... 12	FBA data out 3 ... FBA data out12	See parameter 01 FBA data out 1 .	0

¹⁾ The number of parameters in this group may vary by drive type and drive firmware.

²⁾ 11 (CW 32bit) is the default setting if the Transparent 32 profile is used.

³⁾ With an ACS355 drive, Control word and REF 1 are always fixed to virtual addresses 1 and 2 respectively. If REF2 is used, its virtual address is always 3.

⁴⁾ 2 (Ref1 16bit) is a fixed setting with an ACS355 drive.

FPBA-01 configuration parameters – group C (group 3)

Note: The actual parameter group number depends on the drive type. Group C (group 3) corresponds to:

- parameter group 54 in ACS355
- parameter group 52 in ACSM1, ACS380, ACS580, ACS850, ACQ580, and ACQ810
- parameter group 52 in ACS880 and ACS880-M04 if the adapter is installed as fieldbus adapter A or group 55 if the adapter is installed as fieldbus adapter B.

No. ¹⁾	Name/Value	Description	Default						
01	FBA data in 1 (drive to master)	Selects the resolution of status word (16 bit or 32 bit) sent by the drive.	4 or 14 ²⁾						
	4 = SW 16bit	Status word (16 bits)							
	14 = SW 32bit	Status word (32 bits)							
02	FBA data in 2 (drive to master)	Selects data word 1 sent by the drive over the PROFIBUS network. The content is defined by a decimal number in the range of 0 to 9999 as follows:<table><tr><td>0</td><td>Not used</td></tr><tr><td>1...99</td><td>Virtual address area of drive control</td></tr><tr><td>101...9999</td><td>Parameter area of the drive</td></tr></table> See also Virtual address allocation with ACSM1 on page 51.	0	Not used	1...99	Virtual address area of drive control	101...9999	Parameter area of the drive	0 or 5 ³⁾
0	Not used								
1...99	Virtual address area of drive control								
101...9999	Parameter area of the drive								
	0 = None	Not used							
	4 = SW 16bit	Status word (16 bits)							
	5 = Act1 16bit	Actual value ACT1 (16 bits)							
	6 = Act2 16bit	Actual value ACT2 (16 bits)							
	14 = SW 32bit	Status word (32 bits)							
	15 = Act1 32bit	Actual value ACT1 (32 bits)							

50 Start-up

No. ¹⁾	Name/Value	Description	Default
	16 = Act2 32bit	Actual value ACT2 (32 bits)	
	24 = SW2 16bit	Status word 2 (16 bits)	
	101...9999	Parameter index with format xxyy , where xx is the parameter group number (1...99) yy is the parameter number index within that group (01...99).	
	Other	Path to parameter area selection.	
03... 12	FBA data in 3... FBA data in12	See parameter 01 FBA data in 1.	0

¹⁾ The number of parameters in this group may vary by drive type and drive firmware.

²⁾ 14 (SW 32bit) is the default setting if the Transparent 32 profile is used.

³⁾ 5 (Act1 16bit) is a fixed setting with an ACS355 drive.

Virtual address allocation with ACSM1

When the PROFIdrive profile or PROFIdrive positioning mode is used with an ACSM1 drive, the virtual addresses shown below are recommended. (FBA REFx mode is selected with drive parameter **50.04/50.05**.)

The information in the table is applicable only if PPO messaging is used (see parameter **04 MSG type**). If standard telegrams (STx) are used, virtual addresses for standard telegrams (ST1 and ST2) are updated automatically.

Abbreviation	Description	Data length	Recommended virtual address with ACSM1 FBA REFx modes	
			Speed mode	Position mode
STW1	Control word 1	16-bit	1	1
NSOLL_A	Speed set point A	16-bit	2 or 3	
NSOLL_B	Speed set point B	32-bit	12 or 13	
STW2	Control word 2	16-bit	21	21
XSOLL_A	Position set point A	32-bit		12 or 13
VELOCITY_A	Velocity	32-bit		13
ZSW2	Status word 2	16-bit	24	24
NIST_A	Speed actual value A	16-bit	5 or 6	
NIST_B	Speed actual value B	32-bit	15 or 16	
ZSW1	Status word 1	16-bit	4	4
XIST_A	Position actual value A	32-bit		15 or 16

■ Control locations

ABB drives can receive control information from multiple sources including digital inputs, analog inputs, the drive control panel and a communication module (for e.g., the adapter module). ABB drives allow the user to separately determine the source for each type of control information (Start, Stop, Direction, Reference, Fault reset, etc.).

To give complete control of the fieldbus master station over the drive, select communication module as the source for this information. The drive-specific parameter setting examples below contain the drive control parameters needed in the examples. For a complete parameter list, see the drives documentation.

Starting up ACS355 drives

1. Power up the drive.
 2. Enable the communication between the adapter module and the drive by setting parameter **9802 COMM PROT SEL** to EXT FBA.
 3. Set the FPBA-01 configuration parameters in group 51. At the minimum, set the required node address in parameter **5102** and the communication profile in **5105**.
 4. With parameter **3018 COMM FAULT FUNC**, select how the drive reacts to a fieldbus communication break.
 5. With parameter **3019 COMM FAULT TIME**, define the time between communication break detection and the selected action.
 6. Define the process data transferred to and from the drive in the FPBA-01 configuration parameter groups 54 and 55.
Note: The adapter module sets the Status word and actual value automatically in parameters **5401** and **5402**, and Control word and reference in parameters **5501** and **5502**.
 7. Validate the settings made in parameter groups 51, 54 and 55 by setting parameter **5127 FBA PAR REFRESH** to REFRESH.
 8. Set the relevant drive control parameters to control the drive according to the application. Examples of appropriate values are shown in the tables below.
-

■ **Parameter setting examples – ACS355**

Speed control using the PROFIdrive communication profile with PPO Type 2

This example shows how to configure a basic speed control application that uses the PROFIdrive profile. In addition, some application-specific data is added to the communication.

The start/stop commands and reference are according to the PROFIdrive profile. For more information, see the PROFIdrive state machine on page [111](#).

The reference value ± 16384 (4000h) corresponds to parameter **1105 REF1 MAX** in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Constant speed 1 ¹⁾	Constant speed 2 ¹⁾	N/A	N/A
In	Status word	Speed actual value	Power ¹⁾	DC bus voltage ¹⁾	N/A	N/A

¹⁾ Example

The table below gives the recommended drive parameter settings

Drive parameter	Setting for ACS355 drives	Description
9802 COMM PROT SEL	4 = EXT FBA	Enables communication between the drive and the fieldbus adapter module.
5101 FBA TYPE	PROFIBUS-DP ¹⁾	Displays the type of the fieldbus adapter module.
5102 FB PAR 2 (NODE ADDRESS)	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.

Drive parameter	Setting for ACS355 drives	Description
5103 FB PAR 3 (BAUD RATE)	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
5104 FB PAR 4 (TELEGRAM TYPE)	2 (= PPO2) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
5105 FB PAR 5 (PROFILE)	0 (= PROFIdrive)	Selects the Control word according to the PROFIdrive profile (speed control mode).
3018 COMM FAULT FUNC	3 = LAST SPEED	Enables fieldbus communication fault monitoring.
3019 COMM FAULT TIME	3.0 s	Defines the fieldbus communication break supervision time.
5401 FBA DATA IN 1	4 (= SW 16bit) ¹⁾	Status word
5402 FBA DATA IN 2	5 (= Act1 16bit) ¹⁾	Actual value 1 (speed)
5403 FBA DATA IN 3	106 ²⁾	Power
5404 FBA DATA IN 4	107 ²⁾	DC bus voltage
5501 FBA DATA OUT 1	1 (= CW 16bit) ¹⁾	Control word
5502 FBA DATA OUT 2	2 (= Ref1 16bit) ¹⁾	Reference 1 (speed)
5503 FBA DATA OUT 3	1202 ²⁾	Constant speed 1
5504 FBA DATA OUT 4	1203 ²⁾	Constant speed 2
5127 FBA PAR REFRESH	1 = REFRESH	Validates the FPBA-01 configuration parameter settings.
1001 EXT1 COMMANDS	10 = COMM	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.

Drive parameter	Setting for ACS355 drives	Description
1103 REF1 SELECT	8 = COMM	Selects the fieldbus reference 1 as the source for speed reference 1.
1601 RUN ENABLE	7 = COMM	Selects the fieldbus interface as the source for the inverted Run enable signal (Run disable).
1604 FAULT RESET SEL	8 = COMM	Selects the fieldbus interface as the source for the fault reset signal.

1) Read-only or automatically detected/set

2) Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)

Speed and torque control using the ABB Drives communication profile with PPO Type 4

This example shows how to configure a speed and torque control application that uses the ABB Drives profile. From the PLC programming point, the ABB Drives profile is similar to the PROFIdrive profile shown in the first example.

The start/stop commands and reference are according to the ABB Drives profile. For more information, see section [ABB Drives communication profile](#) on page 115.

When Reference 1 (REF1) is used, a reference value of ± 20000 (decimal) corresponds to the reference set by parameter 1105 REF1 MAX in the forward and reverse directions.

When Reference 2 (REF2) is used, a reference value of ± 10000 (decimal) corresponds to the reference set by parameter 1108 REF2 MAX in the forward and reverse directions.

The minimum and maximum 16-bit integer values that can be given through the fieldbus are -32768 and 32767 respectively.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Torque reference	N/A	N/A	N/A
In	Status word	Speed actual value	Torque actual	N/A	N/A	N/A

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS355 drives	Description
9802 COMM PROT SEL	4 = EXT FBA	Enables communication between the drive and the fieldbus adapter module.
5101 FBA TYPE	PROFIBUS-DP ¹⁾	Displays the type of the fieldbus adapter module.

Drive parameter	Setting for ACS355 drives	Description
5102 FB PAR 2 (NODE ADDRESS)	4 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
5103 FB PAR 3 (BAUD RATE)	1500 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
5104 FB PAR 4 (TELEGRAM TYPE)	4 (= PPO4) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
5105 FB PAR 5 (PROFILE)	1 (= ABB DRIVES)	Selects the Control word according to the ABB Drives profile.
3018 COMM FAULT FUNC	3 = LAST SPEED	Enables fieldbus communication fault monitoring.
3019 COMM FAULT TIME	3.0 s	Defines the fieldbus communication break supervision time.
5401 FBA DATA IN 1	4 (= SW 16bit) ¹⁾	Status word
5402 FBA DATA IN 2	5 (= Act1 16bit) ¹⁾	Actual value 1 (speed)
5403 FBA DATA IN 3	6 (= Act2 16bit) ²⁾	Actual value 2 (torque)
5501 FBA DATA OUT 1	1 (= CW 16bit) ¹⁾	Control word
5502 FBA DATA OUT 2	2 (= Ref1 16bit) ¹⁾	Reference 1 (speed)
5503 FBA DATA OUT 3	3 (= Ref2 16bit) ²⁾	Reference 2 (torque)
5127 FBA PAR REFRESH	1 = REFRESH	Validates the FPBA-01 configuration parameter settings.

Drive parameter	Setting for ACS355 drives	Description
9904 MOTOR CTRL MODE	2 = VECTOR: TORQ	Selects the vector control mode as the motor control mode.
1001 EXT1 COMMANDS	10 = COMM	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.
1002 EXT2 COMMANDS	10 = COMM	Selects the fieldbus interface as the source of the start and stop commands for external control location 2.
1102 EXT1/EXT2 SEL	8 = COMM	Enables external control location 1/2 selection through the fieldbus.
1103 REF1 SELECT	8 = COMM	Selects the fieldbus reference 1 as the source for speed reference 1.
1106 REF2 SELECT	8 = COMM	Selects the fieldbus reference 2 as the source for speed reference 1.
1601 RUN ENABLE	7 = COMM	Selects the fieldbus interface as the source for the inverted Run enable signal (Run disable).
1604 FAULT RESET SEL	8 = COMM	Selects the fieldbus interface as the source for the fault reset signal.

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)
C7Fh (3199 decimal)	OPERATING (Torque mode)

Starting up ACSM1 drives

1. Power up the drive.
 2. Enable the communication between the adapter module and the drive by setting parameter **50.01 FBA ENABLE** to **Enable**.
 3. With parameter **50.02 COMM LOSS FUNC**, select how the drive reacts to a fieldbus communication break.
Note that this function monitors both communication between the fieldbus master and the adapter module and communication between the adapter module and the drive.
 4. With parameter **50.03 COMM LOSS T OUT**, define the time between communication break detection and the selected action.
 5. Select application-specific values for parameters **50.04...50.11**. Examples of appropriate values are shown in the tables below.
 6. Set the FPBA-01 configuration parameters in group 51. At the minimum, set the required node address in parameter **51.02** and the communication profile in **51.05**.
 7. Define the process data transferred to and from the drive in the FPBA-01 configuration parameter groups 52 and 53.
Note: The adapter module sets the Status word and Control word automatically in parameters **52.01** and **53.01**.
 8. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter **51.27 FBA PAR REFRESH** to **REFRESH**.
 9. Set the relevant drive control parameters to control the drive according to the application. Examples of appropriate values are shown in the tables below.
-

■ **Parameter setting examples – ACSM1**

Speed control using the PROFIdrive communication profile with PPO Type 2

This example shows how to configure a basic speed control application that uses the PROFIdrive profile. In addition, some application-specific data is added to the communication.

The start/stop commands and reference are according to the PROFIdrive profile, speed control mode. For more information, see the PROFIdrive state machine on page [111](#).

The reference value ±16384 (4000h) corresponds to parameter **25.02 SPEED SCALING** in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Constant speed ¹⁾		Speed reference for Jogging function 1 ¹⁾	
In	Status word	Speed actual value	Power ¹⁾		DC bus voltage ¹⁾	

¹⁾ Example

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACSM1 drives	Description
50.01 FBA ENABLE	Enable	Enables communication between the drive and the fieldbus adapter module.
50.02 COMM LOSS FUNC	Last speed	Enables fieldbus communication fault monitoring.
50.03 COMM LOSS T OUT	3.0 s	Defines the fieldbus communication break supervision time.

Drive parameter	Setting for ACSM1 drives	Description
50.04 FBA REF1 MODESEL	Speed	Selects the fieldbus reference 1 scaling.
51.01 FBA TYPE	PROFIBUS-DP ¹⁾	Displays the type of the fieldbus adapter module.
51.02 FBA PAR2 (NODE ADDRESS)	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 FBA PAR3 (BAUD RATE)	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 FBA PAR4 (TELEGRAM TYPE)	2 (= PPO2) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 FBA PAR5 (PROFILE)	0 (= PROFIdrive)	Selects the Control word according to the PROFIdrive profile (speed control mode).
52.01 FBA DATA IN1	4 (= SW 16bit) ¹⁾	Status word
52.02 FBA DATA IN2	5 (= Act1 16bit)	Actual value 1 (speed)
52.03 FBA DATA IN3	122 ²⁾	Power
52.05 FBA DATA IN5	107 ²⁾	DC bus voltage
53.01 FBA DATA OUT1	1 (= CW 16bit) ¹⁾	Control word
53.02 FBA DATA OUT2	2 (= Ref1 16bit)	Reference 1 (speed)
53.03 FBA DATA OUT3	2508 ²⁾	Constant speed
53.05 FBA DATA OUT5	2410 ²⁾	Speed reference for Jogging function 1
51.27 FBA PAR REFRESH	REFRESH	Validates the FPBA-01 configuration parameter settings.

Drive parameter	Setting for ACSM1 drives	Description
10.01 EXT1 START FUNC	FBA	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.
10.08 FAULT RESET SEL	P.FBA MAIN CW.8	Selects the fieldbus interface as the source for fault reset.
24.01 SPEED REF1 SEL	FBA REF1	Selects the fieldbus reference 1 as the source for speed reference 1.
34.03 EXT1 CTRL MODE1	Speed	Selects speed control as the control mode 1 for external control location 1.

1) Read-only or automatically detected/set

2) Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)

Position control using the PROFIdrive communication profile with PPO Type 4

This example shows how to configure a basic positioning application. The start/stop commands and reference are according to the PROFIdrive profile, positioning mode. For more information, see the PROFIdrive state machine on page [112](#).

Note: By default, fieldbus is not the only control source. For details of actual signal **02.12 FBA MAIN CW**, see in ACSM1 motion control program firmware manual.

The position set point and velocity reference are defined as 32-bit integer values; both are scaled as defined by drive parameter settings.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word (STW1)	Position set point		Velocity reference		N/A
In	Status word (ZSW1)	Position actual value		Velocity actual value		N/A

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACSM1 drives	Description
50.01 FBA ENABLE	Enable	Enables communication between the drive and the fieldbus adapter module.
50.02 COMM LOSS FUNC	Fault	Enables fieldbus communication fault monitoring.
50.03 COMM LOSS T OUT	3.0 s	Defines the fieldbus communication break supervision time.
50.04 FBA REF1 MODESEL	Position	Selects the fieldbus reference 1 scaling.
50.05 FBA REF2 MODESEL	Velocity	Selects the fieldbus reference 2 scaling.

Drive parameter	Setting for ACSM1 drives	Description
51.01 FBA TYPE	PROFIBUS-DP ¹⁾	Displays the type of the fieldbus adapter module.
51.02 FBA PAR2 (NODE ADDRESS)	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 FBA PAR3 (BAUD RATE)	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 FBA PAR4 (TELEGRAM TYPE)	4 (= PPO4) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 FBA PAR5 (PROFILE)	4 (= PROFIdrive P)	Selects the Control word according to the PROFIdrive positioning mode.
52.01 FBA DATA IN1	4 (= SW 16bit) ¹⁾	Status word
52.02 FBA DATA IN2	15 (= Act1 32bit)	Actual value 1
52.04 FBA DATA IN4	16 (= Act2 32bit)	Actual value 2
53.01 FBA DATA OUT1	1 (= CW 16bit) ¹⁾	Control word
53.02 FBA DATA OUT2	12 (= Ref1 32bit)	Reference 1
53.04 FBA DATA OUT4	13 (= Ref2 32bit)	Reference 2
51.27 FBA PAR REFRESH	REFRESH	Validates the FPBA-01 configuration parameter settings.
10.01 EXT1 START FUNC	FBA	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.
22.01 SPEED FB SEL	Enc1 speed ²⁾	Selects the actual speed measured by encoder 1 as the speed feedback.

Drive parameter	Setting for ACSM1 drives	Description
34.02 EXT1 MODE 1/2SEL	P.FBA MAIN CW.26	Selects the source for external 1 control mode 1/2 selection. Selection is done by START_HOMING bit (bit 26 in the fieldbus Control word). Mode 1: Position, Mode 2: Homing
34.03 EXT1 CTRL MODE1	Position	Selects position control as the control mode 1 for external control location 1.
34.04 EXT1 CTRL MODE2	Homing	Selects homing control as the control mode 2 for external control location 1.
62.01 HOMING METHOD	CAN Methodxx	Selects the homing mode. Select the appropriate CAN Method.
62.03 HOMING START	C.False	Selects the fieldbus as the homing start source.
65.01 POS REFSOURCE	Fieldbus	Position reference and speed are read from the fieldbus.
65.03 POS START 1	C.False	Selects the fieldbus as the position start1 source.
65.04 POS REF 1 SEL	FBA REF 1	Selects the FBA reference 1 as the position reference source.
65.11 POS START 2	C.False	Selects the fieldbus as the position start2 source.
65.22 PROF VEL REF SEL	FBA REF2	Selects the FBA reference 2 as the velocity reference source.

Drive parameter	Setting for ACSM1 drives	Description
66.05 POS ENABLE	C.False	Selects the fieldbus as the source for enabling the position reference generator.
70.03 POS REF ENA	C.False	Selects the fieldbus as the source for the position reference enable command.


- 1) Read-only or automatically detected/set
- 2) Example

The position set point is scaled as follows:

Drive parameter	Setting
60.05 POS UNIT (Position unit)	m ¹⁾
60.08 POS2INT SCALE	100 ¹⁾

- 1) Example

The position set point and actual values are scaled with the above example values as follows:




Example for velocity set point scale:

Drive parameter	Value	Description
60.10 POS SPEED UNIT	u/s ¹⁾	Unit/s (in this case m/s)
60.11 POS SPEED2INT	100 ¹⁾	Scales position speed values to integer values. Selections: 1/10/100/1000/10000/100000

¹⁾ Example

The velocity set point and actual values are scaled with the above example values as follows:



Pay attention to the following parameter groups:

Parameter group	Description
90	Encoder selection
91/92/93	Settings of the encoder

The start sequence for the above parameter example is given below:

Control word	Start sequence
406h (1030 decimal)	READY TO SWITCH ON
40Fh (1039 decimal)	OPERATING
43Fh (1087 decimal)	OPERATING (Reject traversing task with no intermediate stop)
47Fh (1151 decimal)	OPERATING (Activate traversing task)
C0Fh (3087 decimal)	OPERATING (Start Homing procedure)

Speed and torque control using the ABB Drives communication profile with PPO Type 4

This example shows how to configure a speed and torque control application that uses the ABB Drives profile. From the PLC programming point, the ABB Drives profile is similar to the PROFIdrive profile shown in the first example.

The start/stop commands and reference are according to the ABB Drives profile. For more information, see section [ABB Drives communication profile](#) on page 115.

When Reference 1 (REF1) is used, a reference value of ± 20000 (4E20h) corresponds to the reference set by parameter **25.02 SPEED SCALING** in the forward and reverse directions.

When Reference 2 (REF2) is used, a reference value of ± 10000 (2710h) corresponds to the reference set by parameter **32.04 TORQUE REF 1 MAX** in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Torque reference	N/A	N/A	N/A
In	Status word	Speed actual value	Torque actual	N/A	N/A	N/A

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACSM1 drives	Description
50.01 FBA ENABLE	Enable	Enables communication between the drive and the fieldbus adapter module.
50.02 COMM LOSS FUNC	Fault	Enables fieldbus communication fault monitoring.
50.03 COMM LOSS T OUT	3.0 s	Defines the fieldbus communication break supervision time.
50.04 FBA REF1 MODESEL	Speed	Selects the fieldbus reference 1 scaling.

Drive parameter	Setting for ACSM1 drives	Description
50.05 FBA REF2 MODESEL	Torque	Selects the fieldbus reference 2 scaling.
51.01 FBA TYPE	PROFIBUS-DP ¹⁾	Displays the type of the fieldbus adapter module.
51.02 FBA PAR2 (NODE ADDRESS)	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 FBA PAR3 (BAUD RATE)	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 FBA PAR4 (TELEGRAM TYPE)	4 (= PPO4) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 FBA PAR5 (PROFILE)	1 (= ABB DRIVES)	Selects the Control word according to the ABB Drives profile.
52.01 FBA DATA IN1	4 (= SW 16bit) ¹⁾	Status word (PZD 1)
52.02 FBA DATA IN2	5 (= Act1 16bit) ²⁾	Actual value 1
52.03 FBA DATA IN3	6 (= Act2 16bit) ²⁾	Actual value 2
53.01 FBA DATA OUT1	1 (= CW 16bit) ¹⁾	Control word
53.02 FBA DATA OUT2	2 (= Ref1 16bit) ²⁾	Reference 1
53.03 FBA DATA OUT3	3 (= Ref2 16bit) ²⁾	Reference 2
51.27 FBA PAR REFRESH	REFRESH	Validates the FPBA-01 configuration parameter settings.
10.01 EXT1 START FUNC	FBA	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.

72 Start-up

Drive parameter	Setting for ACSM1 drives	Description
10.04 EXT2 START FUNC	FBA	Selects the fieldbus interface as the source of the start and stop commands for external control location 2.
24.01 SPEED REF1 SEL	FBA REF1	Selects the fieldbus reference 1 as the source for speed reference 1.
32.02 TORQ REF ADD SEL	FBA REF2	Selects the fieldbus reference 2 as the source for torque reference 1.
34.01 EXT1/EXT2 SEL	P.FBA MAIN CW.15	Enables external control location 1/2 selection through the fieldbus only (bit 15 in the fieldbus Control word).
34.03 EXT1 CTRL MODE1	Speed	Selects speed control as the control mode 1 for external control location 1.
34.05 EXT2 CTRL MODE1	Torque	Selects torque control as the control mode 1 for external control location 2.

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)
C7Fh (3199 decimal)	OPERATING (Torque mode)

Starting up ACS380 drives

The ACS380 software automatically sets the relevant parameters when the fieldbus adapter module is connected to the drive. Automatic configuration is only minimum configuration, and you can change these parameters later, e.g., Node address.

Parameter	General setting
20.01 Ext1 commands	Fieldbus A
20.03 Ext1 in1	Not selected
20.04 Ext1 in2	Not selected
22.11 Ext1 speed ref1	FB A ref1
22.22 Constant speed sel1	Not selected
22.23 Constant speed sel2	Not selected
23.11 Ramp sel selection	Acc/Dec time 1
28.11 Ext1 frequency ref1	FB A ref1
28.22 Constant frequency sel1	Not selected
28.23 Constant frequency sel2	Not selected
28.71 Freq ramp set sel	Acc/Dec time 1
31.11 Fault reset selection	DI1
50.01 FB A enable	Enable
50.02 FB A comm loss func	Fault
51.02 Node address	3
51.05 Profile	ABB Drives
52.01 FBA A data in1	SW 16 bit
52.02 FBA A data in 2	Act1 16 bit
53.01 FBA A data out1	CW 16 bit
53.02 FBA A data out2	Ref1 16 bit

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)

■ **Setting up the drive for fieldbus control manually**

The fieldbus adapter module is typically pre-installed. The device automatically recognizes the module. If the adapter is not pre-installed, you can install it mechanically and electrically.

1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the user’s manual of the module.
 2. Power up the drive.
 3. Enable the communication between the drive and the fieldbus adapter module with parameter **50.01 FBA A enable**.
 4. With parameter **50.02 FBA A comm loss func**, select how the drive should react to a fieldbus communication break.
- Note:** This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.
5. With parameter **50.03 FBA A comm loss t out**, define the time between communication break detection and the selected action.
 6. Select application-specific values for rest of the parameters in group **50 Fieldbus adapter** (FBA), starting from parameter **50.04**. Examples of appropriate values are shown in the tables below.
 7. Set the fieldbus adapter module configuration parameters in group **51 FBA A settings**. As a minimum, set the required node address and the communication profile.
 8. Define the process data transferred to and from the drive in parameter groups **52 FBA A data in** and **53 FBA A data out**.
-

Note: Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.

9. Save the valid parameter values to permanent memory by setting parameter **96.07 Parameter save manually** to Save.
 10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter **51.27 FBA A par refresh** to Configure.
 11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus.parameter changes, or after changing the fieldbus module.
-

Starting up ACS850 and ACQ810 drives

1. Power up the drive.
 2. Enable the communication between the adapter module and the drive by setting parameter **50.01 FBA enable** to Enable.
 3. With parameter **50.02 Comm loss func**, select how the drive reacts to a fieldbus communication break.
Note that this function monitors both communication between the fieldbus master and the adapter module and communication between the adapter module and the drive.
 4. With parameter **50.03 Comm loss t out**, define the time between communication break detection and the selected action.
 5. ACQ810 only: With parameter **50.21 Comm loss enable**, select in which control locations communication loss detection is active.
 6. Select application-specific values for parameters **50.04...50.11**. Examples of appropriate values are shown in the tables below.
 7. Set the FPBA-01 configuration parameters in group 51. At the minimum, set the required node address in parameter **51.02** and the communication profile in **51.05**.
 8. Define the process data transferred to and from the drive in the FPBA-01 configuration parameter groups 52 and 53.
Note: The adapter module sets the Status word and Control word automatically in parameters **52.01** and **53.01**.
-

9. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter **51.27 FBA par refresh** to Refresh.
 10. Set the relevant drive control parameters to control the drive according to the application. Examples of appropriate values are shown in the tables below.
-

■ **Parameter setting examples – ACS850 and ACQ810**

Speed control using the PROFIdrive communication profile with PPO Type 2

This example shows how to configure a basic speed control application that uses the PROFIdrive profile. In addition, some application-specific data is added to the communication.

The start/stop commands and reference are according to the PROFIdrive profile, speed control mode. For more information, see the PROFIdrive state machine on page [111](#).

The reference value ± 16384 (4000h) corresponds to parameter **19.01 Speed scaling** in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Constant speed 1 ¹⁾		Constant speed 2 ¹⁾	
In	Status word	Speed actual value	Power ¹⁾		DC bus voltage ¹⁾	

¹⁾ Example

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS850/ACQ810 drives	Description
50.01 Fba enable	Enable	Enables communication between the drive and the fieldbus adapter module.
50.02 Comm loss func	Fault	Enables fieldbus communication fault monitoring.
50.03 Comm loss t out	3.0 s	Defines the fieldbus communication break supervision time.
50.04 Fb ref1 modesel	Speed	Selects the fieldbus reference 1 scaling.

Drive parameter	Setting for ACS850/ACQ810 drives	Description
(ACQ810 only) 50.21 Comm loss enable	bit 0 = 1	Enables communication loss detection for EXT 1.
51.01 FBA type	Profibus-DP ¹⁾	Displays the type of the fieldbus adapter module.
51.02 FBA par2 (NODE ADDRESS)	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 FBA par3 (BAUD RATE)	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 FBA par4 (TELEGRAM TYPE)	2 (= PPO2) ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 FBA par5 (PROFILE)	0 (= PROFIdrive)	Selects the Control word according to the PROFIdrive profile (speed control mode).
52.01 FBA data in1	4 (= SW 16bit) ¹⁾	Status word
52.02 FBA data in2	5 (= Act1 16bit)	Actual value 1 (speed)
52.03 FBA data in3	122 ²⁾	Power (32-bit)
52.05 FBA data in5	107 ²⁾	DC bus voltage (32-bit)
53.01 FBA data out1	1 (= CW 16bit) ¹⁾	Control word
53.02 FBA data out2	2 (= Ref1 16bit)	Reference 1 (speed)
53.03 FBA data out3	2606 ²⁾	Constant speed 1 (32-bit)
53.05 FBA data out5	2607 ²⁾	Constant speed 2 (32-bit)
51.27 FBA par refresh	Refresh	Validates the FPBA-01 configuration parameter settings.

Drive parameter	Setting for ACS850/ ACQ810 drives	Description
10.01 Ext1 start func	FB	Selects the fieldbus interface as the source of the start and stop commands for external control location 1.
10.08 FAULT RESET SEL	P.FBA MAIN CW.8	Selects fieldbus interface as the source for fault reset.
21.01 Speed ref1 sel (ACS850) 21.01 Speed ref sel (ACQ810)	FBA ref1 FBA ref1	Selects the fieldbus reference 1 as the source for speed reference 1.

- 1) Read-only or automatically detected/set
- 2) Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)

Starting up ACS880 and ACS880-M04 drives

1. Power up the drive.
 2. Enable communication between the adapter module and the drive by setting parameter **50.01 FBA A Enable**, option slot 1, 2 or 3 depending on the slot the adapter module is attached to.
 3. With parameter **50.02 FBA A comm loss func**, select how the drive reacts to a fieldbus communication break.
Note: This function monitors communication both between the fieldbus master and the adapter module and between the adapter module and the drive.
 4. With parameter **50.03 FBA A comm loss t out**, define the time between communication break detection and the selected action.
 5. Select application-specific values for the rest of the parameters in group 50, starting from parameter **50.04 FBA A ref1 type**. Examples of appropriate values are shown in the tables below.
 6. Set the FPBA-01 configuration parameters in group 51. At the minimum, set the required node address in parameter **51.02 Node address** and the communication profile in **51.05 Profile**.
 7. Define the process data transferred to and from the drive in FPBA-01 configuration parameter groups 52 and 53.
-

Note: The adapter module sets the Status word and Control word automatically in parameters **52.01 FBA A data in1** and **53.01 FBA A data out1**.

- 8. Save the valid parameter values to permanent memory by setting parameter **96.07 Parameter save manually** to Save.
- 9. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter **51.27 FBA A par refresh** to Refresh.
- 10. Set the relevant drive control parameters to control the drive according to the application. Examples of appropriate values are shown in the tables below.

■ **Parameter setting examples – ACS880 and ACS880-M04**

Speed control using the PROFIdrive communication profile with PPO Type 2

This example shows how to configure a basic speed control application that uses the PROFIdrive profile.

The start/stop commands and reference are according to the PROFIdrive profile, speed control mode. For more information, see the PROFIdrive state machine on page [111](#).

The reference value ± 16384 (4000h) corresponds to parameter **46.01 Speed scaling** in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Constant speed 1		Constant speed 2	
In	Status word	Speed actual value	Motor current		DC voltage	

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS880 drives	Description
50.01 FBA A enable	1 = Option slot 1	Enables communication between the drive and the fieldbus adapter A module (if adapter is in slot 1).
50.04 FBA A ref1 type	4 = Speed	Selects the fieldbus A reference 1 type and scaling.
50.07 FBA A actual 1 type	4 = Speed	Selects the actual value type and scaling according to the currently active Ref1 mode defined in parameter 50.04 .
51.01 FBA A type	1 = FPBA ¹⁾	Displays the type of the fieldbus adapter module.
51.02 FBA A Par2	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 Baud rate	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 MSG type	1 = PPO1 ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 Profile	0 = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).
51.07 Emul mode	0 = Disabled	Disables the emulation mode.
52.01 FBA A data in1	4 = SW 16bit ¹⁾	Status word
52.02 FBA A data in2	5 = Act1 16bit	Actual value 1
52.03 FBA A data in3	1.7 [32] ²⁾	Motor current

84 Start-up

Drive parameter	Setting for ACS880 drives	Description
52.05 FBA A data in5	1.11 [32] ²⁾	DC voltage
53.01 FBA A data out1	1 = CW 16bit ¹⁾	Control word
53.02 FBA A data out2	2 = Ref1 16bit	Reference 1 (speed)
53.03 FBA A data out3	22.26 [32] ²⁾	Constant speed 1
53.05 FBA A data out5	22.27 [32] ²⁾	Constant speed 2

51.27 FBA A par refresh	1 = Refresh	Validates the FPBA-01 configuration parameter settings.
-------------------------	-------------	---

19.12 Ext1 control mode	2 = Speed	Selects speed control as the control mode 1 for external control location 1.
20.01 Ext1 commands	12 = Fieldbus A	Selects the fieldbus A interface as the source of the start and stop commands for external control location 1.
20.02 Ext1 start trigger type	1 = Level	Selects the start trigger type to be level.
22.11 Speed ref1 source	FB A ref1	Selects the fieldbus A reference 1 as the source for speed reference 1.

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word	Start sequence
47Eh (1150 decimal)	READY TO SWITCH ON
47Fh (1151 decimal)	OPERATING (Speed mode)

Configuring the master station

After the adapter module is initialized by the drive, prepare the master station for communication with the module. See examples of an ABB AC500 PLC and Siemens SIMATIC S7 PLC given below. If you are using another master system, refer to its documentation for more information.

The examples can be applied to all drive types compatible with the module.

■ Downloading the GSD file

Configuration of the master station requires a type definition (GSD) file. Download the FPBA-01 GSD file from the Document library (<http://new.abb.com/drives/connectivity/fieldbus-connectivity/profibus/profibus-dp-fpba>).

Communication type	File name
DP-V0	ABB_0959.GSD
DP-V1	ABB10959.GSD


The GSD file describes the vendor-specific and PROFIdrive-specific features of the adapter module. Vendor-specific features can be used, for example, in the ABB Drives communication profile. The PROFIdrive profile supports a set of services described in the PROFIdrive specification.

■ Configuring an ABB AC500 PLC


This example shows how to configure the communication between an ABB AC500 PLC and the adapter module using the Automation Builder software, version 1.2 and later.

Before you start, make sure that you have downloaded the FPBA-01 GSD file from the Document library.

1. Start the Automation Builder software.
2. On the **Tools** menu, select **Device Repository**.
3. Click **Install...** and browse for the GSD file.



4. Open or create the PLC project that is used to control the drive.
5. Add the PROFIBUS master (CM572-DP or CM592-DP) device to the PLC.
6. Add the FPBA-01 module to the PROFIBUS network.
7. Add the DP module, for example, PPO Type 4 to the FPBA-01 module to define cyclical communication between the adapter module and the PLC.
8. Define the CM572-DP master properties, such as the Baud rate, Node address (Station address) and the Highest station address.



9. Define the FPBA-01 properties:
On the **DP-Parameters** tab,
 - select the Node address (Station address) and the DP Mode

88 Start-up

- configure the Fail-safe functionality.


The screenshot shows the configuration interface for ABB drives. The top bar includes project names: PPO_04_0_PKW_6_PZD, ABB_Drives_FPBA_01_DP_V1, Profibus_Master, and PLC_AC500. The left sidebar has a tree view with 'General' selected, and sub-items: 'Check configuration', 'I/O mapping list', and 'Information'. The main area is divided into sections: 'Identification' (Station address: 4, Ident number: 0x0959), 'Parameter' (I_SDR (tBit): 11, Lock/Unlock: 2 (Lock)), and 'Watchdog' (Watchdog control: checked, Time (ms): 400). Below these is the 'User parameters' section, which includes a checkbox for 'Symbolic values' and a 'Length of user parameters (Byte): 34' field. A 'Defaults' button is also present. The main table lists various parameters with their current values and allowed ranges.

Parameter	Value	Allowed values
DP Mode	DPV1	Bit(7) 0 0-1
Process Alarm	Disabled	Bit(6) 0 0-0
Diagnostic Alarm	Disabled	Bit(5) 0 0-0
Update Alarm	Disabled	Bit(2) 0 0-0
Alarm Mode	Type mode	BitArea(0-2) 0 0-0
Prm Structure	Enabled	Bit(3) 1 1-1
Length of User Data	30	Unsigned8 30 30-30
Structure Type	129	Unsigned8 129 129-129
Slot	0	Unsigned8 0 0-0
Reserved	0	Unsigned8 0 0-0
Fail Safe mode	Stop	BitArea(0-1) 0 0-2
Control-zero mode	Use data	BitArea(2-3) 0 0-1
Failsafe Timeout(0 = No timeout)	30	Unsigned16 30 0-65535
PZD1 Failsafe value	1150	Unsigned16 1150 0-65535
PZD2 Failsafe value	0	Unsigned16 0 0-65535
PZD3 Failsafe value	0	Unsigned16 0 0-65535
PZD4 Failsafe value	0	Unsigned16 0 0-65535
PZD5 Failsafe value	0	Unsigned16 0 0-65535
PZD6 Failsafe value	0	Unsigned16 0 0-65535
PZD7 Failsafe value	0	Unsigned16 0 0-65535
PZD8 Failsafe value	0	Unsigned16 0 0-65535
PZD9 Failsafe value	0	Unsigned16 0 0-65535
PZD10 Failsafe value	0	Unsigned16 0 0-65535
PZD11 Failsafe value	0	Unsigned16 0 0-65535
PZD12 Failsafe value	0	Unsigned16 0 0-65535

Note: If Fail-Safe Timeout = 0, then the drive's communication fault function is disabled.

10. Define the DP module properties:


On the **DP-module I/O Mapping** tab, type names for the variables that refer to the drive's signals in the PLC program.



11. Open the PLC program and create a program that controls the drive.

12. Compile the project and download it to the PLC.

Note: Make sure that the variable names defined for the drive signals are used in the PLC program. Otherwise the communication will not work.




■ Configuring a Siemens SIMATIC S7 PLC

This example shows how to configure the communication between a Siemens SIMATIC S7 PLC and the adapter module using SIMATIC Manager Step 7.

Before you start, make sure that you have downloaded the FPBA-01 GSD files from the Document library.


1. Start the SIMATIC Manager and open or create a SIMATIC program.
2. Open the hardware configuration of the project.
3. Add PROFIBUS master system.
 - Right- click **X2** and choose **Add Master System**.
 - Click **New**.
 - Check that the network settings are valid and click **OK**.




4. Install the FPBA GSD file:
 - On the Options menu, select **Install GSD files**.
 - Browse for the GSD file downloaded from the Document library and click **Install**.

92 Start-up


- Choose the GSD file based on the software version of the module (see underside of the module) and what DP extension version will be used.



- Click and drag the FPBA-01 object from the device catalog to the PROFIBUS(1): DP master system(1).




- Click and drag the PP0 Type 7 object to slot 1. Then double-click **FPBA**.




The Properties window appears.


- On the General tab, click **PROFIBUS...** and set Node number.



8. Click **Properties** → **Network Settings** and set baud rate.




9. Open the Parameter Assignment tab.
 - Under the **Device-specific parameters** folder configure the Fail Safe mode and Control-zero mode.
 - Enter a Failsafe Timeout value.
 - Configure Failsafe values for the PLC output process data (PZDs).



Note: If Fail-Safe Timeout = 0, then the drive's communication fault function is disabled.

96 Start-up

10. Save and compile the hardware configuration.




11. Download the compiled hardware configuration to the PLC.

The PLC is now ready for communication with the adapter module.

12. If needed, give proper symbol names to the cyclic data:

- Right-click I/O object (PP0 Type 7) and select **Edit Symbols...**
- Add names for the symbols.




■ Configuring a Siemens S7 PLC with TIA Portal V13

This example shows how to configure the communication between a Siemens SIMATIC S7 PLC and the adapter module using TIA Portal V13.


Before you start, make sure that you have downloaded the FPBA-01 GSD files from the Document library.

98 Start-up

1. Start the TIA portal.
2. Go to **Options** → **Install general station description file (GSD)**.




3. Browse the folder containing FPBA-01 GSD files and select the files (both DP-V0 and DP-V1).




4. Click **Install**.

Wait for two minutes, till the TIA portal updates the Device catalog.


5. In TIA portal, go to Network view. Drag and drop FPBA-01 from the Device catalog to the Network view.



6. Click on **Not assigned** text and select the master to create link between the master and FPBA-01.




7. Go to Device view and select **Slave_1** (FPBA-01). Drag and drop the telegram from Catalog to Device.




100 Start-up

8. In the General tab, set FPBA-01 node address.



9. In the Device-specific parameters, set fail-safe mode, time out and fail-safe values.




10. Compile and download the project.

After the PLC starts, node 3 (FPBA-01) goes online with PPO-08.

■ Cyclic data handling

With FPBA-01, both data-consistent and non-consistent communication can be used, data-consistent meaning that the whole cyclic data frame is transmitted during a single program cycle. Some PLCs handle this internally, but others must be programmed to transmit data-consistent telegrams. For more information, see chapter [Communication protocol](#) on page 131.

For example, Siemens SIMATIC S7 requires the use of special functions SFC15 and SFC14.



Communication profiles

Contents of this chapter


This chapter describes the communication profiles used in the communication between the PROFIBUS network, the adapter module and the drive.

Communication profiles

Communication profiles are ways of conveying control commands (Control word, Status word, references and actual values) between the master station and the drive.

With the FPBA-01 module, the PROFIBUS network can use either the PROFIdrive v4.2, legacy PROFIdrive (referred to as PROFIdrive from here on) or the ABB Drives profile. All are converted to the native profile (for example, DCU or FBA) by the adapter module. In addition, two Transparent modes – for 16-bit and 32-bit words respectively – are available. With the Transparent modes, no data conversion takes place.

The figure below illustrates the profile selection:



¹⁾ Native profile (e.g., DCU or FBA)

Note: The diagram is applicable only when PPO messaging is used. If standard telegrams (ST) are used, the communication profile is selected automatically.

The sections that follow describe the Control word, the Status word, references and actual values for the PROFdrive v4.2, PROFdrive and ABB Drives communication profiles. Refer to the drive manuals for details on the native profiles.

PROFIdrive communication profile

■ Control word and Status word

The Control word (PROFIdrive parameter **967**) is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word and returns status information to the master in the Status word (PROFIdrive parameter **968**).

The contents of the Control word and the Status word are detailed below. See the drives documentation for information on drive-specific bits. The drive states for all operating modes are presented on page [111](#). The drive states for the positioning mode are presented on page [112](#).

Control word contents

The table below shows the contents of the Control word for the PROFIdrive communication profile (PROFIdrive parameter **967**). The upper case boldface text refers to the states shown in the state machine on page [111](#).

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
0	ON	1	Proceed to READY TO OPERATE .	
	OFF1	0	Emergency OFF, stop by the selected deceleration ramp. Proceed to OFF1 ACTIVE ; proceed further to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.	
1	OFF2	1	Continue operation (OFF2 inactive).	
		0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE ; proceed further to SWITCH-ON INHIBIT .	

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
2	OFF3	1	Continue operation (OFF3 inactive).	
		0	Emergency stop, stop according to fastest possible deceleration mode. Proceed to OFF3 ACTIVE ; proceed further to SWITCH-ON INHIBIT .  WARNING! Make sure that the motor and driven machine can be stopped using this stop mode.	
3	OPERATION_ENABLE	1	Proceed to ENABLE OPERATION .	
		0	Inhibit operation. Proceed to OPERATION INHIBIT .	
4	ENABLE_RAMP_GENERATOR or	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: ENABLE OUTPUT .	Normal operation. Do not reject traversing task.
	TRAVERSING_TASK	0	Stop according to selected stop type.	Reject traversing task.
5		1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: ENABLE ACCELERATOR .	Normal operation. No intermediate stop.
		0	Halt ramping (Ramp Function Generator output held).	Intermediate stop

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
6		1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.	Activate traversing task (0 → 1). This is a toggle bit; each rising edge of signal enables a traversing task or a new set point.
		0	Force Ramp Function Generator input to zero.	
7	RESET	0 → 1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBIT . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.	
		0	(Continue normal operation)	
8	JOGGING_1		Jogging 1 (Not supported by all drive types)	
9	JOGGING_2		Jogging 2 (Not supported by all drive types)	
10	REMOTE_CMD	1	Fieldbus control enabled	
		0	Control word <> 0 or reference <> 0: Retain last Control word and reference. Control word = 0 and reference = 0: Fieldbus control enabled.	
11		1	Vendor-specific bit as defined by PROFIdrive parameter 933 .	Start homing procedure.
		0		Stop homing procedure.
12			Vendor-specific bit as defined by PROFIdrive parameter 934	

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
13			Vendor-specific bit as defined by PROFIdrive parameter 935	
14			Vendor-specific bit as defined by PROFIdrive parameter 936	
15			Vendor-specific bit as defined by PROFIdrive parameter 937	

Status word contents


The table below shows the contents of the Status word for the PROFIdrive communication profile (PROFIdrive parameter **968**). The upper case boldface text refers to the states shown in the state machine on page [111](#).

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
0	RDY_ON	1	READY TO SWITCH ON	
		0	NOT READY TO SWITCH ON	
1	RDY_RUN	1	READY TO OPERATE	
		0	OFF1 ACTIVE	
2	RDY_REF	1	ENABLE OPERATION	
		0	DISABLE OPERATION	
3	TRIPPED	1	FAULT	
		0	No fault	
4	OFF_2_STA	1	OFF2 inactive	
		0	OFF2 ACTIVE	
5	OFF_3_STA	1	OFF3 inactive	
		0	OFF3 ACTIVE	
6	SWC_ON_INHIB	1	SWITCH-ON INHIBIT ACTIVE	
		0	SWITCH-ON INHIBIT NOT ACTIVE	
7	ALARM	1	Warning/Alarm	
		0	No Warning/Alarm	
8	AT_SETPOINT	1	OPERATING. Actual value equals reference value (= is within tolerance limits).	
		0	Actual value differs from reference value (= is outside tolerance limits).	
9	REMOTE	1	Drive control location: REMOTE	
		0	Drive control location: LOCAL	

Bit	Name	Value	STATE/Description	
			Speed control mode	Positioning mode
10		1	Actual frequency or speed value equals or is greater than supervision limit.	Target position reached
		0	Actual frequency or speed value is within supervision limit.	Not at target position
11		1	Vendor-specific bit as defined by PROFIdrive parameter 939	Homing procedure was executed and is valid.
		0		No valid home position available
12		1	Vendor-specific bit as defined by PROFIdrive parameter 940	Traversing task acknowledgement (0 → 1)
		0		
13		1	Vendor-specific bit as defined by PROFIdrive parameter 941	Drive stopped.
		0		Drive moving. Traversing task is executed (n <> 0).
14			Vendor-specific bit as defined by PROFIdrive parameter 942	
15			Vendor-specific bit as defined by PROFIdrive parameter 943	

State machine for positioning mode

The PROFIdrive state machine for the positioning mode is shown below.



■ References

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a communication module (for example, FPBA-01). In order to have the drive controlled through PROFIBUS, the communication module must be defined as the source for control information, for example, reference.

References in speed control mode

In the speed control mode, references are 16-bit or 32-bit words containing a sign bit and a 15-bit or 31-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

A 16-bit speed reference (REF or NSOLL_A) in hexadecimal (0...4000h) corresponds to 0...100% of speed scaling value (as defined with a drive parameter).

A 32-bit speed reference (NSOLL_B) in hexadecimal (0...4000 0000h) corresponds to 0...100% of speed scaling value (as defined with a drive parameter).

References in positioning mode (ACSM1 only)

In the positioning mode, references are 16-bit or 32-bit words. A 32-bit reference contains a sign bit and a 31-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

For a 32-bit position reference (XSOLL_A), the unit and scaling are defined with drive parameters (for example, **POS UNIT**, **POS2INT SCALE** and **FEED CONST**).

For a 32-bit velocity reference (VELOCITY_A), the unit and scaling are defined with drive parameters (for example, **POS SPEED UNIT** and **POS SPEED2INT**).

■ Actual values

Actual values are 16-bit or 32-bit words containing information on the operation of the drive. The functions to be monitored are selected with a drive parameter.

Actual values in speed control mode

The scaling of 16-bit actual speed values (ACT or NIST_A) in hexadecimal (0...4000h) corresponds to 0...100% of speed scaling value (as defined with a drive parameter).

The scaling of 32-bit actual speed values (NIST_B) in hexadecimal (0...4000 0000h) corresponds to 0...100% of speed scaling value (as defined with a drive parameter).

Actual values in positioning mode (ACSM1 only)

For a 32-bit actual position value (XIST_A), the unit and scaling are defined with drive parameters (for example, **POS UNIT**, **POS2INT SCALE** and **FEED CONST**).

ABB Drives communication profile

■ Control word and Status word

The Control word is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word and returns status information to the master in the Status word.

The contents of the Control word and the Status word are detailed below. The drive states are presented on page 120.

Control word contents

The table below shows the contents of the Control word for the ABB Drives communication profile. The upper case boldface text refers to the states shown on page 120.

Bit	Name	Value	STATE/Description
0	OFF1_ CONTROL	1	Proceed to READY TO OPERATE .
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2_ CONTROL	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED .
2	OFF3_ CONTROL	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED .  WARNING! Make sure that the motor and driven machine can be stopped using this stop mode.

Bit	Name	Value	STATE/Description
3	INHIBIT_ OPERATION	1	Proceed to OPERATION ENABLED . Note: Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED .
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED .
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ ZERO	1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0 → 1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.
8...9	Drive-specific (For information, see the drive documentation)		

Bit	Name	Value	STATE/Description
10	REMOTE_CMD	1	Fieldbus control enabled
		0	Control word and reference not getting through to the drive, except for CW bits OFF1, OFF2 and OFF3.
11	EXT_CTRL_LOC	1	Select External Control Location EXT2. Effective if control location parameterized to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location parameterized to be selected from fieldbus.
12... 15	Drive-specific (For information, see the drive documentation.)		

Status word contents


The table below shows the contents of the Status word for the ABB Drives communication profile. The upper case boldface text refers to the states shown on page [120](#).

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON
		0	NOT READY TO SWITCH ON
1	RDY_RUN	1	READY TO OPERATE
		0	OFF1 ACTIVE
2	RDY_REF	1	OPERATION ENABLED
		0	OPERATION INHIBITED
3	TRIPPED	1	FAULT
		0	No fault
4	OFF_2_STA	1	OFF2 inactive
		0	OFF2 ACTIVE
5	OFF_3_STA	1	OFF3 inactive
		0	OFF3 ACTIVE.
6	SWC_ON_INHIB	1	SWITCH-ON INHIBITED
		0	–
7	ALARM	1	Warning/alarm
		0	No warning/alarm
8	AT_SETPOINT	1	OPERATION. Actual value equals reference value (= is within tolerance limits, i.e., in speed control, speed error is 10% maximum of the nominal motor speed). Note that tolerance limit can be configured in the drive side, for example, speed window in this case.
		0	Actual value differs from reference (= is outside tolerance limits).

Bit	Name	Value	STATE/Description
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2)
		0	Drive control location: LOCAL
10	ABOVE_LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit
11	EXT_CTRL_LOC	1	External Control Location EXT2 selected
		0	External Control Location EXT1 selected
12	EXT_RUN_ENABLE	1	External Run Enable signal received
		0	No External Run Enable signal received
13... 14	Drive-specific (For information, see the drive documentation.)		
15	FBA_ERROR	1	Communication error detected by fieldbus adapter module
		0	Fieldbus adapter communication OK

State machine

The state machine for the ABB Drives communication profile is shown below.



■ References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a communication module (for example, FPBA-01). In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information, for example, reference.

Scaling


References are scaled as shown below.

Note: The values of REF1 MAX and REF2 MAX are set with drive parameters. See the drive manuals for further information.

In ACSM1, ACS850 and ACQ810, the speed reference (REFx) in decimal (0...20000) corresponds to 0...100% of the speed scaling value (as defined with a drive parameter).

In ACS880 and ACS580 the speed reference (REFx) in decimal 0 corresponds to the speed ref min parameter (**46.06 Speed ref zero scaling** in ACS880) or 0 if this parameter does not exist and the speed reference (REFx) in decimal 20000 corresponds to the speed scaling value (as defined with a drive parameter).

In ACS355, drive parameter REFx MIN may limit the actual minimum reference.




■ **Actual values**

Actual values are 16-bit words containing information on the operation of the drive. The functions to be monitored are selected with a drive parameter.

Scaling

Actual values are scaled as shown below.

Note: The values of REF1 MAX and REF2 MAX are set with drive parameters. See the drive manuals for further information.



PROFIdrive v4.2 communication profile

Supported drives

PROFIdrive v4.2 full state machine is supported with ACS880, ACS580 and ACS380 drives with specific version of the drive's software. For more information, refer to the drive's firmware manual.

Control word and Status word

The Control word (PROFIdrive parameter 967) is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word and returns status information to the master in the Status word (PROFIdrive parameter 968).

The contents of the Control word and the Status word are detailed below. See the drives documentation for information on drive-specific bits. The drive states are shown on page 127.

Control word contents

The table below shows the contents of the Control word for the PROFIdrive v4.2 communication profile. The upper case boldface text refers to the states shown on page 127.

Bit	Name	Value	STATE/Description
0	ON	1	Proceed to READY TO OPERATE .
	OFF1	0	Emergency OFF, stop by the selected deceleration ramp. Proceed to RAMP STOP ; proceed further to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to stop. Proceed to SWITCHING ON INHIBITED .

Bit	Name	Value	STATE/Description
2	OFF3	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop according to the fastest possible deceleration mode. Proceed to QUICK STOP; proceed further to SWITCHING ON INHIBITED.  WARNING! Make sure that the motor and driven machine can be stopped using this stop mode.
3	OPERATION_ENABLE	1	Proceed to ENABLE OPERATION .
		0	Inhibit operation. Proceed to READY TO OPERATE .
4	ENABLE_RAMP_GENERATOR	1	Normal operation. Enables the ramp function generator's output.
		0	Ramp function generator's output is forced to zero.
5	UNFREEZE_RAMP_GENERATOR	1	Normal operation. Turns on the ramp function generator.
		0	Ramp function generator's output is frozen to its current value.
6	ENABLE_SETPPOINT	1	Normal operation. Sets the velocity reference as the ramp function generator's input.
		0	Ramp function generator's input is forced to zero.
7	RESET	0 → 1	Fault reset if an active fault exists.
		0	Continue normal operation.
8	JOGGING_1		Not supported in PROFIdrive v4.2 profile.
9	JOGGING_2		Not supported in PROFIdrive v4.2 profile.
10	REMOTE_CMD	1	Fieldbus control enabled
		0	

Bit	Name	Value	STATE/Description
11	EXT_CTRL_LOC		Vendor-specific bit.
12			Vendor-specific bit. Mapped to Drive Main CW bit 12.
13			Vendor-specific bit. Mapped to Drive Main CW bit 13.
14			Vendor-specific bit. Mapped to Drive Main CW bit 14.
15			Vendor-specific bit. Not used.

Status word contents

The table below shows the contents of the Status word for the PROFIdrive v4.2 communication profile. The upper case boldface text refers to the states shown on page [127](#).


Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON
		0	Not READY TO SWITCH ON
1	RDY_RUN	1	READY TO OPERATE
		0	Not READY TO OPERATE
2	RDY_REF	1	OPERATION ENABLED
		0	Operation disabled
3	TRIPPED	1	FAULT
		0	No fault
4	OFF_2_STA	1	OFF2 inactive
		0	OFF2 active
5	OFF_3_STA	1	OFF3 inactive
		0	OFF3 active
6	SWC_ON_INHIB	1	SWITCHING ON INHIBITED
		0	Not SWITCHING ON INHIBITED
7	ALARM	1	Warning/alarm
		0	No warning/alarm

Bit	Name	Value	STATE/Description
8	SPEED_ERROR_WITHIN_TOLERANCE_RANGE	1	Actual value is within tolerance limits of ramp function generator's output. Note: The behavior is different from PROFIdrive's status word bit 8 (AT_SETPOINT).
		0	Actual value is outside tolerance limits of ramp function generator's output.
9	REMOTE	1	Automation system is requested to assume control.
		0	Control by automation system is not possible. Control is possible only at the device or by another interface.
10	ABOVE_LIMIT	1	Actual frequency or speed value equals or is larger than supervision limit.
		0	Actual frequency or speed value is within supervision limit.
11			Vendor-specific bit. Mapped to Drive Main SW bit 11.
12			Vendor-specific bit. Mapped to Drive Main SW bit 12.
13			Vendor-specific bit. Mapped to Drive Main SW bit 13.
14			Vendor-specific bit. Mapped to Drive Main SW bit 14.
15			Vendor-specific bit. Not used.

State machine

The state machine and definitions for the PROFIdrive v4.2 communication profile are shown below. The jogging mode is not available in PROFIdrive v4.2.

Symbol	Definition
n	Speed
	State transition priority. Transitions with more circles have a higher priority. A transition with no circles has the lowest priority.
	Rising edge of the bit
	Condition



For PROFIdrive v4.2, the ramp function generator operates the same as in the PROFIdrive profile. The only difference is that if the PROFIdrive control word bit4 is set to false while in the **RAMP STOP** state, the drive stops as fast as possible within the current and DC voltage limits. This occurs because setting bit4 to false forces the output of the ramp function generator to 0.

■ References

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. To have the drive controlled through PROFINET, you must select the module as the source for control information, for example, reference.

References in speed control mode

In the speed control mode, references are 16-bit or 32-bit words containing a sign bit and a 15-bit or 31-integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

A 16-bit speed reference (REF or NSOLL_A) in hexadecimal (0...4000h) corresponds to 0...100% of Maximum Reference (as defined with a drive parameter).

A 32-bit speed reference (NSOLL_B) in hexadecimal (0...4000 0000h) corresponds to 0...100% of Maximum Reference (as defined with a drive parameter).

■ Actual values

Actual values are 16-bit or 32-bit words containing information on the operation of the drive. The functions to be monitored are selected with a drive parameter.

Actual values in speed control mode

The scaling of 16-bit actual speed values (ACT or NIST_A) in hexadecimal (0...4000h) corresponds to 0...100% of the maximum reference (as defined with a drive parameter, for example, speed scaling in ACS880).

The scaling of 32-bit actual speed values (NIST_B) in hexadecimal (0...4000 0000h) corresponds to 0...100% of the maximum reference (as defined with a drive parameter, for example, speed scaling in ACS880).

Communication protocol

Contents of this chapter

This chapter describes the PROFIBUS messaging used in the communication with the drive and in PROFIBUS slave device configuration messages.

PROFIBUS DP

The FPBA-01 module supports the PROFIBUS DP-V0 and DP-V1 protocols according to the IEC 61158, IEC 61784 and EN 50170 standards. PROFIBUS DP-V0/DP-V1 is a distributed I/O system which enables the master to use a large number of peripheral modules and field devices. The data transfer is mainly cyclic: the master reads the input information from the slaves and sends the output information back to the slaves.

The FPBA-01 module uses so-called PPOs (parameter/process data objects) in cyclic communication and also supports standard telegrams 1 and 2. See section [Cyclical message types](#) on page 149 for the supported PPO messages and standard telegrams.

■ **Service access points (SAPs)**

The services of the PROFIBUS Data Link Layer (Layer 2) are used by PROFIBUS DP through service access points (SAPs). Precisely defined functions are assigned to individual SAPs.

For further information on SAPs, refer to the manual of the PROFIBUS master, *PROFIDRIVE – The PROFIBUS Profile for Adjustable Speed Drives V2.0 and V3.1*, or the EN 50170 and IEC 61784 standards.

■ **Communication start-up**

The following service access points (SAPs) are used to initiate DP communication:

SAP no.	Short name	Name
Default SAP (0)	Data_Exch	Cyclical Data Exchange (Write_Read_Data)
58	Global_Control	Global Control Service
59	Get_Cfg	Read Configuration Data
60	Slave_Diag	Read Diagnostic Data
61	Set_Prm	Send Parameter Data
62	Chk_Cfg	Check Configuration Data

PROFIBUS SD2 telegram for Default SAP (0) and SAP 58-62

PROFIBUS typically uses SD2 telegrams for DP communication. The structure of an SD2 telegram is shown below.

DP header										DP trailer	
SD	LE	LEr	SD	DA	SA	FC	*DSAP	*SSAP	DU	FCS	ED
68h	x	x	68h	xx	xx	x	xx	xx	x...	xx	16h
SD = Start delimiter LE = Length LEr = Length repeated DA = Destination address SA = Source address FC = Function code *DSAP = Destination service access point *SSAP = Source service access point DU = Data unit for DP services FCS = Frame checking sequence ED = End delimiter *Not present with Default SAP (0)									Data unit See the descriptions of each SAP on the following pages.		

Default SAP (SAP 0) (Data_Exch)

This SAP allows the master to send output data to a slave station and to simultaneously request input data from the same station.

	Output Data	Input Data
Data	Outp_Data	Inp_Data
DU length	4 to 32 bytes (depending on the selected PPO message or standard telegram type)	

In addition to Default SAP, any master can read the I/O data of any slave at any time using the “Read_Inputs” (SAP 56) and “Read_Outputs” (SAP 57) telegrams. These telegrams have otherwise the same structure as the cyclic Data_Exchange telegram, but include the DSAP and SSAP bytes. In these telegrams, the MSB of the DA and SA bytes is set to 1 to indicate that a DSAP/SSAP byte follows in the telegram header.

For more information, see section [PROFIBUS SD2 telegram for Default SAP \(0\) and SAP 58-62](#) on page 133.

SAP 58 (Global_Control)

This SAP is used to send special commands addressed to a single slave, a special group of slaves, or all slaves at once (broadcast).

Global_Control	
Type: Octet String - Length: 2	
DU Byte	Description
0	GC_Command MSB 0 0 x x x x x 0 LSB Reserved Clear Data 0 = Do not clear output 1 = Clear output Unfreeze Freeze 00 = No function 10 = Activated x1 = Deactivated Un_Sync Sync 00 = No function 10 = Activated x1 = Deactivated Reserved
1	Group_Select 0...255. The value must match the Group Identification number of SAP 61 (DU Byte 6).

SAP 60 (Slave_Diag)

This SAP gives diagnostic information on the slave station.

Diag_Data (Diagnostic Data) Type: Octet String - Length: 6 (Standard) + 2 (Extended Diagnosis) (DP-V0 mode) + 5 (Extended Diagnosis) (DP-V1 mode) Note: During initialization, the module only sends the standard part of the message.	
DU Byte	Description
0	Station_Status_1 MSB x x x x x x x x LSB Diag.Station_Non_Existent (Set by Master, reset by Slave) Slave not found Diag.Stagion_Not_Ready (Set by Slave) Slave not ready for data exchange Diag.Cfg_Fault (Set by Slave) Received configuration data does not match original config. data Diag.Ext_Diag (Set by Slave) Diagnostic entry present in slave-specific diagnostic area Diag.Not_Supported (Set by Slave) Service not supported by slave Diag.Invalid_Slave_Response (Set by Master, reset by Slave) Invalid response by slave Diag.Prm_Fault (Set by Slave) Invalid parameter or parameter value Diag.Master_Lock (Set by Master, reset by Slave) Slave is parameterized by another master

1	Station_Status_2 MSB x 0 x x x 1 x x LSB Diag.Prm_Req (Set by Slave) Slave requires re-configuration and re-parameterization Diag.Stat_Diag (Set by Slave) Static diagnosis. Slave (temporarily) unable to provide valid data. Always set to 1 by slave Diag.WD_On (Set by Slave) Watchdog on Diag.Freeze_Mode (Set by Slave) Freeze command received by slave Diag.Sync_Mode (Set by Slave) Sync command received by slave Reserved Diag.Deactivated (Set by Master, reset by Slave) Slave is inactive
2	Station_Status_3 MSB x 0 0 0 0 0 0 0 LSB Reserved Diag.Ext_Diag_Overflow (Set by slave)
3	Diag.Master_Add The address of the master that parameterized this slave
4...5	Ident_Number (for FPBA-01: 0959h)
6 ²⁾	Ext_Diag_Data (0x02) (DP-V0 only) The number of bytes (including this byte) reserved for Extended Diagnosis

6 ¹⁾	Header Byte (DP-V1 only) The complete header consists of 5 bytes with FPBA-01. MSB 00xxxxxx LSB Block length in bytes including header Diagnostic type 00 = Device-related diagnostic according to PROFIdrive 3.1.
7 ²⁾	Communication Diagnostic (DP-V0 only) MSB 000000xx LSB Communication temporarily lost Communication permanently lost Reserved
7 ¹⁾	Status Type = Status Message (0x81) (DP-V1 only) MSB 1xxxxxxx LSB Diagnostic type 0 = Reserved 1 = Status_Message (normal alarm message) 2 = Module_Status 3 = DXB_Link_Status 4 to 29 = Reserved 30 = PrmCmdAck 31 = Red_State 32 to 126 = Manufacturer-specific 127 = Reserved Set to 1
8 ¹⁾	Slot Number (0x00) (DP-V1 only) Slot Number (0...244).

9 ¹⁾	Specifier (0x00) (DP-V1 only) MSB 0 0 0 0 0 0 x x LSB Specifier Reserved
10 ¹⁾	Communication Diagnostic (DP-V1 only) MSB 0 0 0 0 0 0 x x LSB Communication temporarily lost Communication permanently lost Reserved

1) The FPBA-01 module is operated in the DP-V1 mode. The diagnostic information is according to PROFIdrive 3.1.

2) The FPBA-01 module is operated in the DP-V0 (DP) mode. The diagnostic information is according to PROFIdrive 2.0.

SAP 61 (Set_Prm)

This SAP is used in the parameterization of the drive.

Prm_Data (Parameter Data Standard) Type: Octet String Total length: 37 – Prm_Data length: 14 – User_Prm_Data length: 23		
DU Byte	Value	Description
0	B8h (Recom- mended default value)	Station status MSB x x 1 1 1 0 0 0 LSB Reserved WD_ON 1 = Watchdog ON Freeze_Req 1 = Slave is requested to process in freeze mode Sync_Req 1 = Slave is requested to process in SYNC mode Unlock_Req Lock_Req } 1) 1)00 = Min TSDR and slave-related parameters may be overwritten. 10 = Slave locked for other masters. All parameters can be carried over. x1 = Slave released for other masters.
1...2		WD_Fact_1 and WD_Fact_2 – Watchdog Factors 1 and 2 (set by the PROFIBUS master) WdFactor1 × WdFactor2 × 10 ms = monitoring time of the slave to verify that the master is still active
3	0Bh (Default)	MinTSDR – Minimum Station Delay Respond Time Time after which a slave station is allowed to send response frames to the master. Calculated by multiplying the hex value with t _{Bit} (time required for transmitting one bit).
4...5	0959h	Vendor Identification (for FPBA-01: 0959h)
6	00h	Group Identification

7		DPV1_Status_1 (DP-V1 only) MSB x 0 x 0 0 x x x LSB Dis_Start_Control (Disable Stop-Bit Control) 0 = Start bit monitoring in receiver enabled 1 = Start bit monitoring in receiver disabled Dis_Stop_Control (Disable Stop-Bit Control) 0 = Stop bit monitoring in receiver enabled 1 = Stop bit monitoring in receiver disabled WD_Base (Watchdog time base) 0 = 10 ms 1 = 1 ms Reserved Publisher_Enabled. Not supported. 0 = Slave not operated in DXB Publisher mode 1 = Slave operated in DXB Publisher mode Fail_Safe. Not supported. DPV1_Enable 0 = Slave operated in DP mode 1 = Slave operated in DP-V1 mode
---	--	--

8		DPV1_Status_2 (DP-V1 only) (Not supported) MSB x x x x x x 0 x LSB Chk_Cfg_Mode 0 = Chk_Cfg according to EN 50170 (default state) 1 = User-specific evaluation of Chk_Cfg Reserved. To be parameterized with '0'. Enable_Update_Alarm 0 = Enable_Update_Alarm disabled 1 = Enable_Update_Alarm enabled Enable_Status_Alarm 0 = Enable_Status_Alarm disabled 1 = Enable_Status_Alarm enabled Enable_Manufacturer_Specific_Alarm 0 = Enable_Manufacturer_Specific_Alarm disabled 1 = Enable_Manufacturer_Specific_Alarm enabled Enable_Diagnostic_Alarm 0 = Enable_Diagnostic_Alarm disabled 1 = Enable_Diagnostic_Alarm enabled Enable_Process_Alarm 0 = Enable_Process_Alarm disabled 1 = Enable_Process_Alarm enabled Enable_Pul_Plug_Alarm 0 = Enable_Pull_Plug_Alarm disabled 1 = Enable_Pull_Plug_Alarm enabled
---	--	--

9		DPV1_Status_3 (DP-V1 only) MSB 0 0 0 x 1 x x x LSB Alarm_Mode. Not supported. Limits the number of active alarms. 0 = 1 alarm of each type 1 = 2 alarms in total 2 = 4 alarms in total 3 = 8 alarms in total 4 = 12 alarms in total 5 = 16 alarms in total 6 = 24 alarms in total 7 = 32 alarms in total Prm_Structure 0 = Prm telegram according to EN 50170 1 = Prm telegram in structure form (DPV2 extension) IsoM_Req (Isochron Mode Request) Not supported. 0 = Isochron Mode disabled 1 = Isochron Mode enabled Reserved. To be parameterized with '0'.
10	1Bh (Default)	Structured_Length Length of the structured Prm telegram. (User parameter length is 23 bytes + 4 header bytes.)
11	81h	Structure_Type 129: USER_PRM_DATA
12	0	Slot_Number Set to 0
13	0	Reserved

User_Prm_Data (Parameter Data Extended) Type: Octet String - Length: 23		
14	00h (Default)	Header byte MSB 0 0 0 0 0 x 0 x LSB Fail-safe mode. Defines the action taken when the PLC is switched from 'RUN' to 'STOP' mode. 00 = STOP (default) 01 = LAST REFERENCE 02 = USE FAIL-SAFE. The values of the PZDs are defined by bytes 11-30 in the Prm_Data telegram. Control zero mode. Defines the action taken if a PROFIBUS telegram containing only zeros is received. 00 = USE FRAME (default). Note: With this setting, the drive may not be stopped (if it is running) since bit 10 (Remote Command) in the control word is also zero. However, the other PZDs may still be updated, but have the value zero. 01 = IGNORE Reserved
15... 16	0... 65536	Cut off time out in milliseconds. 0 = Cut off disabled.
17... 18	0... 65536	Fail-safe, PZD1 (typically CW)
19... 20	0... 65536	Fail-safe, PZD2 (typically REF)

21... 22	0... 65536	Fail-safe, PZD3
23... 24	0... 65536	Fail-safe, PZD4
25... 26	0... 65536	Fail-safe, PZD5
27... 28	0... 65536	Fail-safe, PZD6
29... 30	0... 65536	Fail-safe, PZD7
31... 32	0... 65536	Fail-safe, PZD8
33... 34	0... 65536	Fail-safe, PZD9
35... 36	0... 65536	Fail-safe, PZD10

The extended parameter data bytes are configured through the PROFIBUS network configuration tool. The functions are defined in the GSD file.

SAP 62 (Chk_Cfg)

With this telegram, the master sends the selected data exchange (Write_Read_Data) telegram type code to the slave. The table below gives the typical hexadecimal values (DU Byte 0...n) that are sent to the drive in order to select the PPO type or standard telegram (ST).


Telegram name	Cyclical telegram length (in words)	Default code for message type (see figure below)	Supported parameter channel access mode
PPO 1	4 PKW + 2 PZD in/out	F3 F1	DP-V0 / DP-V1 ¹⁾
PPO 2	4 PKW + 6 PZD in/out	F3 F5	DP-V0 / DP-V1 ¹⁾
PPO 3	0 PKW + 2 PZD in/out	F1	DP-V1 ¹⁾
PPO 4	0 PKW + 6 PZD in/out	F5	DP-V1 ¹⁾
PPO 5	4 PKW + 10 PZD in/out	F3 F9	DP-V0 / DP-V1 ¹⁾
PPO 6	0 PKW + 10 PZD in/out	F9	DP-V1 ¹⁾
PPO 7	4 PKW + 12 PZD in/out	0xF3, 0xFB	DP-V0 / DP-V1 ¹⁾
PPO 8	0 PKW + 12 PZD in/out	0xFB	DP-V1 ¹⁾
ST 1	2 PZD in / 2 PZD out	C3 C1 C1 FD 00 01	DP-V1
ST 2	4 PZD in / 4 PZD out	C3 C3 C3 FD 00 02	DP-V1

¹⁾ DP-V1 mode selected by the user.

PKW: "Parameter-Kennung-Wert" (Parameter ID value)

PZD: "Prozeßdaten" (Process data, cyclically transferred)

The default codes for the PPO types in the table above define data consistency over the message as follows:



For example, 11110001 = F1 = PPO3


Data non-consistent over the entire message is also supported by the FPBA-01 module. The cyclical frame types supported by the module are defined in the GSD file.

■ **Other SAPs for DP-V1 communication**

Master class	Master SAP	Slave SAP	Short name	Meaning
C1	51	51	Server SAP	Read, Write, Alarm
C1	51	50	Alarm SAP	Alarm
C2	50	49	Resource Mgmt. SAP	Req PDU
C2	50	48...0	Communication SAP	Abort, Read/Write, Data_Transfer
C2	62	55	Set_Slave_Add	Change Station Address (C2 Master)

Cyclical message types

PPO types



■ **Standard telegram (ST) types (DP-V1)**

ST1		PZD1	PZD2	
	OUT area	STW1 Control word 1	NSOLL_A Speed set point A	
	IN area	ZSW1 Status word 1	NIST_A Speed actual value A	


ST2		PZD1	PZD2...3	PZD4
	OUT area	STW1 Control word 1	NSOLL_B Speed set point B	STW2 Control word 2
	IN area	ZSW1 Status word 1	NIST_B Speed actual value B	ZSW2 Status word 2

Note: For the contents of the Control word, the Status word, references and actual values, see chapter [Communication profiles](#).

Parameter handling in cyclic communication (DP)

Note: Parameter handling in cyclic communication is not defined in PROFIdrive v4.2. All parameter handling requests in cyclic communication are handled by PROFIdrive.

In cyclic PROFIBUS DP communication, parameter data is transferred in PPO message types 1, 2 and 5, as shown in section [PPO types](#) on page 149. The parameter identification part consists of eight bytes, as shown below.



The Request label is used by the master when transmitting data to the slave, while the Response label is used by the slave as a positive or negative acknowledgement. The tables below show the Request/Response functions.

Request labels (from master to slave)			
Request	Function	Response labels	
		Ackn. (+)	Ackn. (-)
0	No task	0	–
1	Request parameter value	1, 2	7
2	Change parameter value (word)	1	7, 8
3	Change parameter value (double word)	2	7, 8
4	Request description element	3	7

Request labels (from master to slave)			
Request	Function	Response labels	
		Ackn. (+)	Ackn. (-)
5	Change description element	3	7, 8
6	Request parameter value (array)	4, 5	7, 8
7	Change parameter value (array word)	4	7, 8
8	Change parameter value (array double word)	5	7, 8
9	Request number of array elements	6	7

Response label (Acknowledgement from slave to master)	
Ackn.	Function
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
3	Transfer description element
4	Transfer parameter value (array word)
5	Transfer parameter value (array double word)
6	Transfer number of array elements

Response label (Acknowledgement from slave to master)	
Ackn.	Function
7	Task cannot be executed, followed by error number 0 = Illegal parameter number 1 = Parameter value cannot be changed 2 = Lower or upper limit violated 3 = Erroneous subindex 4 = No array 5 = Incorrect data type 6 = Setting not allowed (can only be reset) 7 = Descriptive element cannot be changed 9 = Descriptive data not available 11 = No parameter change rights 15 = Text array not available 17 = Task cannot be executed due to operating status (eg, parameter is currently read-only) 18 = Other error 101 = Vendor-specific error 102 = Request not supported 103 = Request cannot be completed due to communication error 110 = Failure during write to non-volatile memory 111 = Request aborted due to time-out 120 = Parameter cannot be mapped to PZD (size mismatch or non-existent) 121 = Parameter cannot be mapped to PZD (end of memory) 122 = Parameter cannot be mapped to PZD (multiple PZD write) 130 = Cannot map Control word bit (parameter 933...937, eg, double mapping of bits) 140 = Cannot change mode to TORQUE (frequency is used) 150 = Internal buffer overflow 160... = Internal communication error 255
8	No parameter change rights for PKW interface
9	Parameter data signal (word)
10	Parameter data signal (double word)

The allocation of drive control/actual words, drive parameters and PROFIdrive parameters to the parameter identification part of the PPO type is shown below.

- The **Index** column corresponds to the parameter number (PNU) in the ID part of parameter identification.
- The **Sub-index** column corresponds to the IND part of parameter identification.
- The **Example No.** column refers to the examples on the following pages.

Virtual drive control area					
Index	Sub-index	Par. No. (Decimal)	Request label		Example. No.
0h	1h	1	R/W	6/7/8 ¹⁾	1, 2
0h	2h	2			
...					
0h	63h	99			

¹⁾ Supported with an ACSM1 drive only

Drive parameters					
Index	Sub-index	Par. No. (Decimal)	Request label		Example No.
1	1	101	R/W	6/7/8 ¹⁾	1, 2
1	2	102			
...					
63h	63h	9999			

¹⁾ Supported with an ACSM1 drive only

PROFIdrive parameters						
Index	Sub-index	Par. No (Decimal)		Request label		Example No.
393h	2h	915	2	R/W	6/7	6
	3h		3			
	...		...			
	9h		9			
394h	2h	916	2	R/W	6/7	7
	3h		3			
	...		...			
	9h		9			
396h	0h	918		R/W	1/2	3, 4
...						
3B3h	0h	947	1	R	6	5
	9h		9			
	11h		17			
	19h		25			
	21h		33			
	29h		41			
...						
3CCh	0h	972		R/W	1/2	3, 4

For a complete PROFIdrive parameter list, see [Appendix A – PROFIdrive parameters](#).

Note: Continuous (cyclic) writing of PROFIdrive parameters should be avoided as the values of these parameters are stored in the flash memory of the adapter module. The estimated lifetime of the flash memory is 100,000 program/erase cycles, and continuous writing will cause the memory to fail prematurely.


■ **Parameter data transfer examples (DP-V0)**

Note: Only the ‘data unit’ part of the telegram is presented in the examples. See section [PROFIBUS SD2 telegram for Default SAP \(0\) and SAP 58-62](#) on page 133.

Example 1: Reading a drive parameter (or data set)


To determine the parameter number and subindex for drive parameter reading, convert the drive parameter group number and the parameter index number to hexadecimal. The index number is the Subindex (IND), and the group number is the Parameter Number (PNU). For example, to read parameter **84.11** from the drive:

84.11 = 54h.0Bh => Parameter Number = 54h, Subindex = 0Bh.



Error response

Resp	DP header	7	5	0	0	0	0	0	0	0	3	3	1	0	0	0	0	0	0	0	DP trailer
		0	4	B	0	0	0	0	3	3	7	4	5	0	0	0	0	0	0	0	




¹⁾ 2nd byte reserved

Example 2: Writing a drive parameter (or data set)

To determine the parameter number and subindex for drive parameter writing, convert the drive parameter group number and the parameter index number to hexadecimal. The index number is the Subindex (IND), and the group number is the Parameter Number (PNU). For example, to write parameter **12.02** to the drive:


12.02 = 0Ch.02h => Parameter number = 0Ch, Subindex = 02h.

The following is an example of writing a 16-bit parameter.




1) 2nd byte reserved

The following is an example of writing a 32-bit parameter:



Example 3: Reading a PROFIdrive parameter (word)

In this example, PROFIdrive parameter 918 is used to read the station number of the slave.




The slave returns its station number (2).

Example 4: Writing a PROFIdrive parameter (word)


In this example, current parameter settings are saved to the FLASH memory of the drive. This is done by setting the value of PROFIdrive parameter 971 (3CBh) to 1.

Note that the drive always observes the Control word (CW) and reference (REF) bytes. The values shown below are examples.



Example 5: Reading a PROFIdrive parameter (array)

In this example, PROFIdrive parameter 945 is used to read the code of the active fault. As shown on page 207, parameter 945 is of the array type with subindexes 0 and 1.



The slave returns the code of the active fault (2300h). The fault codes are according to the DRIVECOM® standard. See the drive firmware manual for drive-specific fault codes.


The implementation of the PROFIdrive profile in the adapter module supports the storage of the active and the five latest occurred different faults in the fault buffer. The fault codes can be accessed by PROFIdrive parameters 945 and 947 (see page 207). The value zero indicates no fault. The subindexes of these parameters are related to each other, that is, parameter 945 with subindex 1 relates to the subindex of parameter 947.

Example 7: Configuring the process data read from the drive

PROFIdrive parameter 916 can be used to define which data is read cyclically from the drive as application-specific process data.

In the example below, drive parameter **1.04** (01h.04h) is selected to be transmitted by the drive as PZD3. The selection is in force until it is superseded by another selection.

Subindex (IND) defines which process data word the required data is transmitted in, and Parameter Value defines which drive parameter is mapped to that word.



Subsequent response frames:


Resp	DP header	x	x	x	x	x	x	x	x	x	x	x	x	0	0	0	B	x	x	x	x	x	x	DP trailer
		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x		

PZD3 (Value of drive parameter 1.04)



■ **DP-V1 read/write request sequence**

A read/write service on a drive parameter is illustrated below.



The messaging employs DP-V1 data units. The PROFIdrive parameter request is included within the DP-V1 request as data. Likewise, the DP-V1 response contains the PROFIdrive parameter response as data.

A write request (Function number 5Fh – see page 168) is first sent containing the parameter request.

If the write request is valid, the adapter module acknowledges it with DP-V1 write response code 5Fh with no data. The

master will then send a read request. If the adapter module is still busy performing the internal parameter request, it will return a negative response with the DP-V1 error code B5h (State conflict). In this case, the read request will be repeated by the master until the adapter module has the PROFIdrive response data ready.

If the write request is invalid, a negative response is returned with a DP-V1 error code (see page [169](#)).

PROFIBUS SD2 telegram for SAP 51

The read/write service uses a variable-length PROFIBUS SD2 telegram shown below.

DP header										DP trailer	
SD	LE	LEr	SD	DA	SA	FC	DSAP	SSAP	DU	FCS	ED
68h	x	x	68h	xx	xx	x	xx	xx	x...	xx	16h
SD = Start delimiter LE = Length LEr = Length repeated DA = Destination address SA = Source address FC = Function code DSAP = Destination service access point SSAP = Source service access point DU = Data unit for DP services FCS = Frame checking sequence ED = End delimiter											

Data unit					
DP-V1 Command/Response				PROFIdrive V3 Parameter Channel	
DU0	DU1	DU2	DU3	Request/Response header (See the tables on pages 170 and 172 .)	Data

Byte	Meaning	Value
DU0	Function number	See page 168 .
DU1	Slot number	0 = Module itself 1 = Drive parameter access
DU2	Index	47 (0x2F)
DU3	Data length	(Depends on type of message)
DU4...DUn	PROFIdrive data	

The table below lists the DP-V1 function numbers.

Value	Meaning
0x48	Idle REQ, RES
0x51	Data transport REQ, RES
0x56	Resource manager REQ
0x57	Initiate REQ, RES
0x58	Abort REQ
0x5C	Alarm REQ, RES
0x5E	Read REQ, RES
0x5F	Write REQ, RES
0xD1	Data transport negative response
0xD7	Initiate negative response
0xDC	Alarm negative response
0xDE	Read negative response
0xDF	Write negative response

The table below lists the DP-V1 error responses.

Byte	Meaning and value
DU0	Function number = 0xDF (Error Write) = 0xDE (Error Read)
DU1	Error_Decompile: PROFIdrive: Always 0x80 (DP-V1 codes)
DU2	Error_Code_1: Error class/error code (see page 169)
DU3	Error_Code_2: Always 0

The table below lists the error codes for the DP-V1 error responses.

Error class	Meaning	Error code
0...9	(Reserved)	
10 (0x0A)	Application	0 = Read error 1 = Write error 2 = Module failure 3...7 = Reserved 8 = Version conflict 9 = Feature not supported 10...15 = User-specific
11 (0x0B)	Access	0 = Invalid index 1 = Write length error 2 = Invalid slot 3 = Type conflict 4 = Invalid area 5 = State conflict 6 = Access denied 7 = Invalid range 8 = Invalid parameter 9 = Invalid type 10...15 = User-specific
12 (0x0C)	Resource	0 = Read constraint conflict 1 = Write constraint conflict 2 = Resource busy 3 = Resource unavailable 4...7 = Reserved 8...15 = User-specific
13...15	User-specific	

The table below shows the contents of the PROFIdrive Request header.

Field(s)	Description	Range	Byte/Word
Request Reference	Unique identification set by the master. Changed for each new request.	1...255	Byte
Request ID	Request type for the issued block	Request Parameter (01h) Change Parameter (02h)	Byte
Drive Object ID	To be set to 0 or 1.	0...255	Byte
No. of Parameters	Number of parameters that are present in the request	1...37	Byte
Attribute	Type of object being accessed Note: “Description” and “Text” are not supported.	Value (10h) Description (20h) Text (30h)	Byte
No. of Elements	Number of array elements accessed or length of string accessed. Set to 0 if non-array parameters are used.	0, 1...234	Byte
Parameter Index	Address of the parameter that is being accessed. “0” is allowed by FPBA-01.	1...65535	Word

Field(s)	Description	Range	Byte/Word
Subindex	Addresses - the first array element of the parameter or - the beginning of a string access or - the text array or - the description element that is being accessed.	0...65535	Word
Format ¹⁾	See the table on page 173.	See the table on page 173.	Byte
Number of Values ¹⁾	Number of values following	0...234	Byte
Values ¹⁾	The values of the request. In case of an odd number of bytes, a zero byte is appended to ensure the word structure of the telegram.	–	See the Format field.

¹⁾ Only if Request ID is 02h (Change Parameter). The Format, Number of Values and Values fields are repeated for other parameters.

The table below shows the contents of the PROFIdrive Response header.

Field(s)	Description	Range
Request Reference (mirrored)	Mirrored from the request	1...255
Response ID	Response from the slave. In case any requested services fail, a “not acknowledged” (NAK) response will be indicated.	Request Param OK (01h) Request Param NAK (81h) Change Param OK (02h) Change Param NAK (82h)
Drive Object ID	To be set to 1.	0...255
No. of Parameters	Number of parameters that are present in the response	1...37
Format ¹⁾	See the table on page 173.	See the table on page 173.
Number of Values ¹⁾	Number of values following	0...234
Values ¹⁾	The values of the request. In case of an odd number of bytes, a zero byte is appended to ensure the word structure of the telegram.	–

¹⁾ Only if Response ID is 01h (Request Parameter OK). The Format, Number of Values and Values fields are repeated for other parameters.

The table below shows the data types for the Format field.

Code	Type
0x00	(Reserved)
0x01...0x36	Standard data types
	1 Boolean (not supported)
	2 Integer8 (not supported)
	3 Integer16
	4 Integer32
	5 Unsigned8 (not supported)
	6 Unsigned16
	7 Unsigned32
	8 Floating point (not supported)
	9 Visible string (not supported)
	...
0x37...0x3F	(Reserved)
0x40	Zero
0x41	Byte
0x42	Word
0x43	Double word
0x44	Error
0x45...0xFF	(Reserved)

The table below shows the PROFIdrive parameter request error codes.

Error #	Meaning	Used at
00h	Impermissible parameter number	Access to an unavailable parameter
01h	Parameter value cannot be changed	Change access to a parameter value that cannot be changed
02h	Low or high limit exceeded	Change access with a value outside the limits
03h	Invalid subindex	Access to an unavailable subindex
04h	No array	Access with a subindex to a non-indexed parameter
05h	Incorrect data type	Change access with a value that does not match the data type of the parameter
06h	Setting not permitted (can only be reset)	Change access with a value unequal to 0 when this is not permitted
07h	Description element cannot be changed	Change access to a description element that cannot be changed
09h	No description data available	Access to an unavailable description (Parameter value is available.)
0Bh	No operation priority	Change access rights without rights to change parameters
0Fh	No text array available	Access to a text array that is not available (Parameter value is available.)
11h	Request cannot be executed because of operating mode	Access is temporarily not possible for reasons that are not specified in detail.
14h	Value impermissible	Change access with a value that is within limits but is not permissible for other long-term reasons (parameter with defined single values)

Error #	Meaning	Used at
15h	Response too long	The length of the current response exceeds the maximum transmittable length.
16h	Parameter address impermissible	Illegal value or value that is not supported for the attribute, number of elements, parameter number or sub-index, or a combination
17h	Illegal format	Write request: Illegal format or format of parameter data that is not supported
18h	Number of values inconsistent	Write request: Number of values of parameter data does not match number of elements at the parameter address
65h...FF	Manufacturer-specific error area	–
65h	Vendor-specific error	Vendor-specific error
66h	Request not supported	Request not supported
67h	Communication error	Request cannot be completed because of a communication error.
6Eh	Non-volatile error	Failure during write to non-volatile memory
6Fh	Time-out error	Request aborted because of timeout
78h	PZD map failure	Parameter cannot be mapped to PZD (size mismatch or non-existent).
79h	PZD memory failure	Parameter cannot be mapped to PZD (out of memory).
7Ah	Multiple PZD map	Parameter cannot be mapped to PZD (multiple PZD write).

Error #	Meaning	Used at
82h	Control word bit map	Cannot map Control word bit (parameter 933...937, eg, double mapping of bits).
8Ch	Set torque mode error	Cannot change mode to TORQUE (frequency is used).
90h	Illegal Request ID	The request ID of the response is illegal.
96h	Internal buffer	Buffer overflow
A0h	Internal communication	Communication error between the module and the drive

■ **Parameter data transfer examples (DP-V1)**

The following examples show how parameter data is transferred using the DP-V1 mechanisms READ and WRITE.


Note: Only the “data unit” part of the SD2 telegram is presented in the examples. See [PROFIBUS SD2 telegram for SAP 51](#) on page [167](#).

Example 1a: Reading a drive parameter (array element)


Note: Drive parameter access is not available in PROFIdrive v4.2 profile. See parameter [05 Profile](#).

Drive parameters are addressed so that the drive parameter group corresponds to the Parameter index (PNU), and the drive parameter number within the group corresponds to the Subindex (IND). In the following example, a value is read from drive parameter number **12.04** (0C.04h).


- DP-V1 Write request (Read parameter value):



- Positive Read response to DP-V1 Read request:



- Negative response to PROFIdrive Read request:




Example 1b: Reading 3 drive parameters (multi-parameter)


Note: Drive parameter access is not available in PROFIdrive v4.2 profile. See parameter [05 Profile](#).

In this example, three parameters (**12.04**, **20.08** and **30.19**) are read using one telegram.

- DP-V1 Write request (Read parameter value):



- Positive Read response to DP-V1 Read request:





The values 190h (400), 1F4h (500) and 1Eh (30) are returned.

Example 2a: Writing a drive parameter (one array element)

Note: Drive parameter access is not available in PROFIdrive v4.2 profile. See parameter [05 Profile](#).

Drive parameters are addressed so that the drive parameter group corresponds to the Parameter index (PNU), and the drive parameter number within that group corresponds to the Subindex (IND). In the following example, a value is written to drive parameter **12.02** (0C.02h).







Example 2b: Writing 2 drive parameters (multi-parameter)

Note: Drive parameter access is not available in PROFIdrive v4.2 profile. See parameter [05 Profile](#).

In this example, the values 300 (12Ch) and 500 (1F4h) are written to drive parameters **12.02** (0C.02h) and **20.08** (14.08h) respectively using one telegram.







Example 3: Reading a PROFIdrive parameter

In this example, PROFIdrive parameter 918 (396h) is used to read the station number of the slave.

- DP-V1 Write request (Reading a PROFIdrive parameter):



- DP-V1 Read response:



The slave returns the station number of the slave (0003h in this example).


Example 4: Configuring the process data written to the drive

PROFIdrive parameter 915 (393h) can be used to define which data is written cyclically to a drive parameter as application-specific process data.


In the example below, the value of drive parameter **12.06** (0C.06h) is selected to be taken from PZD3. The parameter will continue to be updated with the contents of PZD3 in each Request frame until a different selection is made.

Subindex (IND) defines which process data word the required data is taken from. Value selects the drive parameter to which that word is mapped.

- DP-V1 Write request:



- DP-V1 Read response:




Subsequently, the contents of PZD3 in each Request frame are written to drive parameter **12.06** until a different selection is made.


Example 5: Determining the source of process data read from the drive

PROFIdrive parameter 916 (394h) can be used to define which data is read cyclically from the drive as application-specific process data. In the example below, the parameter is used to determine which drive parameter the contents of PZD3 are taken from. Subindex (IND) defines which process data word the required data is transmitted in.

- DP-V1 Write request:



- DP-V1 Read response:



Value indicates the source of PZD3 as drive parameter **12.05** (0C.05h).




Diagnostics


Contents of this chapter

This chapter explains how to trace faults with the status LEDs on the adapter module.

LED indications

The adapter module is equipped with three bicolor diagnostic LEDs. The LEDs are described below.

		
Name	Color	Function
HOST	Green	Connection to host OK
	Blinking red	Establishing communication to host, or communication to host lost
	Flashing orange, alternating with the MODULE flashing orange	Internal file system error. The error may be cleared by cycling drive power. If the error persists, contact your local ABB representative.

HOST MODULE NETWORK 		
Name	Color	Function
MODULE	Green	Module status OK
	Blinking red	Configuration mismatch
	Blinking red in unison with HOST (blinking red)	Establishing communication to host
	Blinking green in unison with NETWORK (blinking red)	Network connection lost
	Blinking green once per second with NETWORK steady green	No communication with this node
	Blinking green 3 times per second with NETWORK steady green	Only Class 2 master connection (no cyclic communication established)
	Red	Module fault
	Flashing orange, alternating with the HOST flashing orange	Internal file system error. The error may be cleared by cycling drive power. If the error persists, contact your local ABB representative.
NETWORK	Blinking green	Establishing network connection
	Green	Network connection OK
	Blinking red	Network connection lost

10


Technical data

Contents of this chapter

This chapter contains the technical data of the adapter module and the PROFIBUS link.

FPBA-01

The figure below shows the enclosure of the adapter module from the front and side.



Mounting	Into the option slot on the drive
Degree of protection	IP20
Ambient conditions	The applicable ambient conditions specified for the drive in its manuals are in effect.
Indicators	Three bicolor LEDs (HOST, MODULE, NETWORK)
Connectors	• 20-pin connector to drive (X2) • 9-pin D-SUB connector to bus (X1)
Power supply	• +3.3 V $\pm 5\%$ max. 450 mA (supplied by the drive) • Isolated +5 V supply available for bus termination circuitry (X1 pins 5 and 6). 30 mA max.
General	• Complies with EMC standard EN 61800-3:2004 • Bus interface functionally isolated from drive • Coated circuit board.

PROFIBUS link

Compatible devices: All PROFIBUS-compliant devices

Medium: Shielded twisted pair RS-485 cable (PROFIBUS-approved cable recommended)

- Termination: 220 ohms, or active termination circuitry at each end of trunk cable (termination not built in the FPBA-01 module)
- Specifications:

Parameter	Line A PROFIBUS DP	Line B DIN 19245 Part 1	Unit
Impedance	35...165 (3...20 MHz)	100...130 (f > 100 kHz)	ohm
Capacitance	< 30	< 60	pF/m
Resistance	< 110	–	ohm/k m
Wire gauge	> 0.64	> 0.53	mm
Conductor area	> 0.34	> 0.22	mm ²

- Maximum bus length:

Transfer rate (kbit/s)	≤ 93.75	187.5	500	1500	3000	6000	1200 0
Line A (m)	1200	1000	400	200	100	100	100
Line B (m)	1200	600	200	–	–	–	–

Topology: Trunk line, drop lines allowed. Max. 126 nodes with repeaters (31 nodes + repeater per section)

Transfer rate: 12 Mb/s max., automatically detected by the adapter module

Serial communication type: Asynchronous, half-duplex RS-485

Protocol: PROFIBUS DP

License information for 3rd party components

Format - lightweight string formatting library.

Copyright (C) 2010-2013, Neil Johnson

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Source code for the "strtod" library procedure.

Copyright (c) 1988-1993 The Regents of the University of California.

Copyright (c) 1994 Sun Microsystems, Inc.

This software is copyrighted by the Regents of the University of California, Sun Microsystems, Inc., Scriptics Corporation, and other parties. The following terms apply to all files associated with the software unless explicitly disclaimed in individual files.

The authors hereby grant permission to use, copy, modify, distribute, and license this software and its documentation for any purpose, provided that existing copyright notices are retained in all copies and that this notice is included verbatim in any distributions. No written agreement, license, or royalty fee is required for any of the authorized uses. Modifications to this software may be copyrighted by their authors and need not follow the licensing terms described here, provided that the new terms are clearly indicated on the first page of each file where they apply.

IN NO EVENT SHALL THE AUTHORS OR DISTRIBUTORS BE LIABLE TO ANY PARTY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, ITS DOCUMENTATION, OR ANY DERIVATIVES THEREOF, EVEN IF THE AUTHORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE AUTHORS AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. THIS SOFTWARE IS PROVIDED ON AN "AS IS" BASIS, AND THE AUTHORS AND DISTRIBUTORS HAVE NO OBLIGATION TO PROVIDE MAINTENANCE, SUPPORT, UPDATES, ENHANCEMENTS, OR MODIFICATIONS.

GOVERNMENT USE: If you are acquiring this software on behalf of the U.S. government, the Government shall have only "Restricted Rights" in the software and related documentation as defined in the Federal Acquisition Regulations (FARs) in Clause 52.227.19 (c) (2). If you are acquiring the software on behalf of the Department of Defense, the software shall be

classified as "Commercial Computer Software" and the Government shall have only "Restricted Rights" as defined in Clause 252.227-7013 (c) (1) of DFARs. Notwithstanding the foregoing, the authors grant the U.S. Government and others acting in its behalf permission to use and distribute the software in accordance with the terms specified in this license.



Appendix A – PROFIdrive parameters

Contents of this chapter

This chapter contains a list of the PROFIdrive profile parameters.

PROFIdrive parameters

Par. no.	R/W ¹⁾	Data type	Description
915	R/W	Array [10] Unsigned16	Assignment PZD1 to PZD10 in PPO-write Note: In PROFIdrive v4.2 mode, the first elements of this parameter have subindex 0. In the PROFIdrive mode, the subindex is 1.
916	R/W	Array [10] Unsigned16	Assignment PZD1 to PZD10 in PPO-read Note: In PROFIdrive v4.2 mode, the first elements of this parameter have subindex 0. In the PROFIdrive mode, the subindex is 1.
918	R/W	Unsigned16	Node address. Writing this parameter will change the node address. Module re-start required.

Par. no.	R/W ¹⁾	Data type	Description								
919	R	<u>PROFIdrive:</u> Octet String4 <u>PROFIdrive</u> <u>v4.2:</u> Visible String	ABB drive product code.								
922	R	Unsigned16	Telegram selection. <table><tr><th>Value</th><th>Description</th></tr><tr><td>0</td><td>Not standard telegram (PPO)</td></tr><tr><td>1</td><td>ST1</td></tr><tr><td>2</td><td>ST2</td></tr></table>	Value	Description	0	Not standard telegram (PPO)	1	ST1	2	ST2
Value	Description										
0	Not standard telegram (PPO)										
1	ST1										
2	ST2										

Par. no.	R/W ¹⁾	Data type	Description																																										
923	R	Array [n] Unsigned16	List of all parameters for signals. Mandatory if process data normalization is used and/or parameters 915 and 916 are implemented. <table><tr><th>No.</th><th>Signal name</th><th>Type</th></tr><tr><td>1</td><td>Control word 1 (STW1)</td><td>Unsigned16</td></tr><tr><td>2</td><td>Status word 1 (ZSW1)</td><td>Unsigned16</td></tr><tr><td>3</td><td>Control word 2 (STW2)</td><td>Unsigned16</td></tr><tr><td>4</td><td>Status word 2 (ZSW2)</td><td>Unsigned16</td></tr><tr><td>5</td><td>Speed set point A (NSOLL_A)</td><td>Signed16</td></tr><tr><td>6</td><td>Speed actual value A (NIST_A)</td><td>Signed16</td></tr><tr><td>7</td><td>Speed set point B (NSOLL_B)</td><td>Signed32</td></tr><tr><td>8</td><td>Speed actual value B (NIST_B)</td><td>Signed32</td></tr><tr><td>27</td><td>Position set point A (XSOLL_A)</td><td>Signed32</td></tr><tr><td>28</td><td>Position actual value A (XIST_A)</td><td>Signed32</td></tr><tr><td>32</td><td>Traversing block selection (SATZANW) (not supported)</td><td>Unsigned16</td></tr><tr><td>33</td><td>Actual traversing block (AKTSATZ) (not supported)</td><td>Unsigned16</td></tr><tr><td>34</td><td>Target position (TARPOS_A) (not supported)</td><td>Signed32</td></tr></table>	No.	Signal name	Type	1	Control word 1 (STW1)	Unsigned16	2	Status word 1 (ZSW1)	Unsigned16	3	Control word 2 (STW2)	Unsigned16	4	Status word 2 (ZSW2)	Unsigned16	5	Speed set point A (NSOLL_A)	Signed16	6	Speed actual value A (NIST_A)	Signed16	7	Speed set point B (NSOLL_B)	Signed32	8	Speed actual value B (NIST_B)	Signed32	27	Position set point A (XSOLL_A)	Signed32	28	Position actual value A (XIST_A)	Signed32	32	Traversing block selection (SATZANW) (not supported)	Unsigned16	33	Actual traversing block (AKTSATZ) (not supported)	Unsigned16	34	Target position (TARPOS_A) (not supported)	Signed32
No.	Signal name	Type																																											
1	Control word 1 (STW1)	Unsigned16																																											
2	Status word 1 (ZSW1)	Unsigned16																																											
3	Control word 2 (STW2)	Unsigned16																																											
4	Status word 2 (ZSW2)	Unsigned16																																											
5	Speed set point A (NSOLL_A)	Signed16																																											
6	Speed actual value A (NIST_A)	Signed16																																											
7	Speed set point B (NSOLL_B)	Signed32																																											
8	Speed actual value B (NIST_B)	Signed32																																											
27	Position set point A (XSOLL_A)	Signed32																																											
28	Position actual value A (XIST_A)	Signed32																																											
32	Traversing block selection (SATZANW) (not supported)	Unsigned16																																											
33	Actual traversing block (AKTSATZ) (not supported)	Unsigned16																																											
34	Target position (TARPOS_A) (not supported)	Signed32																																											

Par. no.	R/W ¹⁾	Data type	Description																											
927	R/W	Unsigned16	Operator control rights (parameter identification, PKW) <table><tr><th>Value</th><th>Mode</th></tr><tr><td>0</td><td>Parameters cannot be written, only read (927 can be written).</td></tr><tr><td>1</td><td>Parameters can be written and read (default).</td></tr></table>	Value	Mode	0	Parameters cannot be written, only read (927 can be written).	1	Parameters can be written and read (default).																					
Value	Mode																													
0	Parameters cannot be written, only read (927 can be written).																													
1	Parameters can be written and read (default).																													
928	R/W	Unsigned16	Control rights (process data, PZD). <table><tr><th>Value</th><th>Mode</th></tr><tr><td>0</td><td>PZD part is disabled, i.e., Receipt of new PZD data is ignored.</td></tr><tr><td>1</td><td>PZD part is enabled (default).</td></tr></table>	Value	Mode	0	PZD part is disabled, i.e., Receipt of new PZD data is ignored.	1	PZD part is enabled (default).																					
Value	Mode																													
0	PZD part is disabled, i.e., Receipt of new PZD data is ignored.																													
1	PZD part is enabled (default).																													
929	R	Unsigned16	Selected PPO type <table><tr><th>Value</th><th>PPO type</th><th>Configuration</th></tr><tr><td>1</td><td>PPO1</td><td>F3h, F1h</td></tr><tr><td>2</td><td>PPO2</td><td>F3h, F5h</td></tr><tr><td>3</td><td>PPO3</td><td>F1h</td></tr><tr><td>4</td><td>PPO4</td><td>F5h</td></tr><tr><td>5</td><td>PPO5</td><td>F3h, F9h</td></tr><tr><td>6</td><td>PPO6</td><td>F9h</td></tr><tr><td>7</td><td>PPO7</td><td>0xF3, 0xFB</td></tr><tr><td>8</td><td>PPO8</td><td>0xFB</td></tr></table> Note: This parameter is not available if standard telegram ST1 or ST2 is selected. Note: this parameter is not available with PROFIdrive v4.2 profile.	Value	PPO type	Configuration	1	PPO1	F3h, F1h	2	PPO2	F3h, F5h	3	PPO3	F1h	4	PPO4	F5h	5	PPO5	F3h, F9h	6	PPO6	F9h	7	PPO7	0xF3, 0xFB	8	PPO8	0xFB
Value	PPO type	Configuration																												
1	PPO1	F3h, F1h																												
2	PPO2	F3h, F5h																												
3	PPO3	F1h																												
4	PPO4	F5h																												
5	PPO5	F3h, F9h																												
6	PPO6	F9h																												
7	PPO7	0xF3, 0xFB																												
8	PPO8	0xFB																												

Par. no.	R/W ¹⁾	Data type	Description																												
930	R/W	Unsigned16	Selection switch for communication profile. Behavior when PROFIdrive v.4.2 is active: <table><tr><th>Value</th><th>Mode</th></tr><tr><td>1</td><td>PROFIdrive v.4.2</td></tr><tr><td>8001h</td><td>ABB Drives</td></tr><tr><td>8002h</td><td>Transparent 16</td></tr><tr><td>8003h</td><td>Transparent 32</td></tr><tr><td>8004h</td><td>PROFIdrive positioning mode</td></tr><tr><td>8005h</td><td>PROFIdrive</td></tr></table> Behavior when any other profile is active: <table><tr><th>Value</th><th>Mode</th></tr><tr><td>1</td><td>PROFIdrive</td></tr><tr><td>8001h</td><td>ABB Drives</td></tr><tr><td>8002h</td><td>Transparent 16</td></tr><tr><td>8003h</td><td>Transparent 32</td></tr><tr><td>8004h</td><td>PROFIdrive positioning mode</td></tr><tr><td>8005h</td><td>PROFIdrive v.4.2</td></tr></table>	Value	Mode	1	PROFIdrive v.4.2	8001h	ABB Drives	8002h	Transparent 16	8003h	Transparent 32	8004h	PROFIdrive positioning mode	8005h	PROFIdrive	Value	Mode	1	PROFIdrive	8001h	ABB Drives	8002h	Transparent 16	8003h	Transparent 32	8004h	PROFIdrive positioning mode	8005h	PROFIdrive v.4.2
Value	Mode																														
1	PROFIdrive v.4.2																														
8001h	ABB Drives																														
8002h	Transparent 16																														
8003h	Transparent 32																														
8004h	PROFIdrive positioning mode																														
8005h	PROFIdrive																														
Value	Mode																														
1	PROFIdrive																														
8001h	ABB Drives																														
8002h	Transparent 16																														
8003h	Transparent 32																														
8004h	PROFIdrive positioning mode																														
8005h	PROFIdrive v.4.2																														
933	R/W	Unsigned16	Selection switch for Control word, bit 11. <table><tr><th>Value</th><th>Module Control word bit</th></tr><tr><td>0</td><td>None</td></tr><tr><td>1 to 5</td><td>Vendor-specific 1 to 5²⁾</td></tr></table> Note: this parameter is not available with PROFIdrive v4.2 profile.	Value	Module Control word bit	0	None	1 to 5	Vendor-specific 1 to 5 ²⁾																						
Value	Module Control word bit																														
0	None																														
1 to 5	Vendor-specific 1 to 5 ²⁾																														
934	R/W	Unsigned16	Selection switch for Control word, bit 12. (See parameter 933 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.																												

Par. no.	R/W ¹⁾	Data type	Description						
935	R/W	Unsigned16	Selection switch for Control word, bit 13. (See parameter 933 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
936	R/W	Unsigned16	Selection switch for Control word, bit 14. (See parameter 933 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
937	R/W	Unsigned16	Selection switch for Control word, bit 15. (See parameter 933 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
939	R/W	Unsigned16	Selection switch for Status word, bit 11. <table border="1"><tr><th>Value</th><th>Module Status word bit</th></tr><tr><td>0</td><td>None</td></tr><tr><td>1 to 4</td><td>Vendor-specific 1 to 4²⁾</td></tr></table> Note: this parameter is not available with PROFIdrive v4.2 profile.	Value	Module Status word bit	0	None	1 to 4	Vendor-specific 1 to 4 ²⁾
Value	Module Status word bit								
0	None								
1 to 4	Vendor-specific 1 to 4 ²⁾								
940	R/W	Unsigned16	Selection switch for Status word, bit 12. (See parameter 939 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
941	R/W	Unsigned16	Selection switch for Status word, bit 13. (See parameter 939 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
942	R/W	Unsigned16	Selection switch for Status word, bit 14. (See parameter 939 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
943	R/W	Unsigned16	Selection switch for Status word, bit 15. (See parameter 939 for coding.) Note: this parameter is not available with PROFIdrive v4.2 profile.						
944	R	Unsigned16	Fault message counter						

Par. no.	R/W ¹⁾	Data type	Description						
945	R	Array[64] Unsigned16	Fault code (coded according to DRIVECOM profile). Supported with ACS355 drives only. Note: The drive may limit the actual number of the faults recorded. <table><tr><th>Subindex</th><th>Contents</th></tr><tr><td>1</td><td>Active fault</td></tr></table>	Subindex	Contents	1	Active fault		
Subindex	Contents								
1	Active fault								
946	R	Array [n] Unsigned16	Fault code list. Contains the mapping between DRIVECOM fault codes and Channel Error Types. If you use a DRIVECOM fault code as an index when reading PNU946, the corresponding Channel Error Type is returned.						
947	R	Array [64] Unsigned16	Fault number. <table><tr><th>Subindex</th><th>Contents</th></tr><tr><td colspan="2">See parameter 945.</td></tr></table>	Subindex	Contents	See parameter 945 .			
Subindex	Contents								
See parameter 945 .									
950	R	Array [2] Unsigned16	Size of the fault buffer <table><tr><th>Subindex</th><th>Contents</th></tr><tr><td>0</td><td>Amount of fault situations</td></tr><tr><td>1</td><td>Amount of fault messages</td></tr></table>	Subindex	Contents	0	Amount of fault situations	1	Amount of fault messages
Subindex	Contents								
0	Amount of fault situations								
1	Amount of fault messages								
952	R/W	Unsigned16	Number of faults occurred. Writing a zero clears the value. Note: this parameter is not available with PROFIdrive v4.2 profile.						
953	R	Unsigned16	³⁾ Last alarm Note: this parameter is not available with PROFIdrive v4.2 profile.						
954	R	Unsigned16	³⁾ Second last alarm Note: this parameter is not available with PROFIdrive v4.2 profile.						

Par. no.	R/W ¹⁾	Data type	Description
955	R	Unsigned16	³⁾ Third last alarm Note: this parameter is not available with PROFIdrive v4.2 profile.
956	R	Unsigned16	³⁾ Fourth last alarm Note: this parameter is not available with PROFIdrive v4.2 profile.
957	R	Unsigned16	³⁾ Fifth last alarm Note: this parameter is not available with PROFIdrive v4.2 profile.
958	R	Unsigned16	Sixth last alarm (not supported) Note: this parameter is not available with PROFIdrive v4.2 profile.
959	R	Unsigned16	Seventh last alarm (not supported) Note: this parameter is not available with PROFIdrive v4.2 profile.
960	R	Unsigned16	Eighth last alarm (not supported) Note: this parameter is not available with PROFIdrive v4.2 profile.
963	R	Unsigned16	Detected baud rate: 0 = 9.6 kbit/s 1 = 19.2 kbit/s 2 = 93.75 kbit/s 3 = 187.5 kbit/s 4 = 500 kbit/s 6 = 1.5 Mbit/s 7 = 3 Mbit/s 8 = 6 Mbit/s 9 = 12 Mbit/s 11 = 45.45 kbit/s 255 = Invalid baud rate

Par. no.	R/W ¹⁾	Data type	Description																
964	R	Array [7] Unsigned16	<table><tr><th>Subindex</th><th>Contents</th></tr><tr><td>0</td><td>Manufacturer code (ABB = 1A)</td></tr><tr><td>1</td><td>Device type = 1</td></tr><tr><td>2</td><td>FW version of FPBA-01</td></tr><tr><td>3</td><td>Firmware date (year)</td></tr><tr><td>4</td><td>Firmware date (day/month)</td></tr><tr><td>5</td><td>Number of Axes</td></tr><tr><td>6</td><td>Identification (0959h)</td></tr></table>	Subindex	Contents	0	Manufacturer code (ABB = 1A)	1	Device type = 1	2	FW version of FPBA-01	3	Firmware date (year)	4	Firmware date (day/month)	5	Number of Axes	6	Identification (0959h)
Subindex	Contents																		
0	Manufacturer code (ABB = 1A)																		
1	Device type = 1																		
2	FW version of FPBA-01																		
3	Firmware date (year)																		
4	Firmware date (day/month)																		
5	Number of Axes																		
6	Identification (0959h)																		
965	R	Octet String2	Profile number of this device. E.g.: 0302h = Profile 3, Version 2																
967	R	Unsigned16	Control word (CW)																
968	R	Unsigned16	Status word (SW)																
970	R/W	Unsigned16	Load parameter record <table><tr><th>Value</th><th>Description</th></tr><tr><td>0</td><td>No action</td></tr><tr><td>1</td><td>Restore factory settings</td></tr></table> The parameter must do a zero-to-one transition and the motor must be stopped. Note: this parameter is not available with PROFIdrive v4.2 profile.	Value	Description	0	No action	1	Restore factory settings										
Value	Description																		
0	No action																		
1	Restore factory settings																		

Par. no.	R/W ¹⁾	Data type	Description						
971	R/W	Unsigned16	Save parameter record <table><tr><th>Value</th><th>Description</th></tr><tr><td>0</td><td>No action</td></tr><tr><td>1</td><td>Save the drive parameters to non-volatile memory</td></tr></table> The parameter must do a zero-to-one transition and the motor must be stopped. Note: this parameter is not available with PROFIdrive v4.2 profile.	Value	Description	0	No action	1	Save the drive parameters to non-volatile memory
Value	Description								
0	No action								
1	Save the drive parameters to non-volatile memory								
972	R/W	Unsigned16	Software reset <table><tr><th>Value</th><th>Description</th></tr><tr><td>0</td><td>No action</td></tr><tr><td>1</td><td>Re-boot PROFIBUS module</td></tr></table> The parameter must do a zero-to-one transition and the motor must be stopped.	Value	Description	0	No action	1	Re-boot PROFIBUS module
Value	Description								
0	No action								
1	Re-boot PROFIBUS module								
975	R	Array[n] Unsigned16	DO identification. For subindexes 0...4, see parameter 964. <table><tr><th>Subindex</th><th>Meaning</th></tr><tr><td>5</td><td>Value 2 = Axis</td></tr><tr><td>6</td><td>Bit 0 = 1 → Application Class 1 supported Bit 2 = 1 → Application Class 3 supported</td></tr></table>	Subindex	Meaning	5	Value 2 = Axis	6	Bit 0 = 1 → Application Class 1 supported Bit 2 = 1 → Application Class 3 supported
Subindex	Meaning								
5	Value 2 = Axis								
6	Bit 0 = 1 → Application Class 1 supported Bit 2 = 1 → Application Class 3 supported								
980 981	R	Array[n] Unsigned16	Number list of the defined parameters. If the subindex is 0, the end of the list has been reached. If the subindex is the number of the next list parameter, the list is continued there. Note: parameter 981 is not available with PROFIdrive v4.2 profile.						

Par. no.	R/W ¹⁾	Data type	Description
60000	R/W	Float32	Velocity reference scaling value. Note: Available for PROFIdrive v4.2 profile only.

¹⁾ Read and/or Write

²⁾ The meaning of vendor-specific bits is defined by the drive application program.

³⁾ Support depends on the drive type.

12

Appendix B – I&M records

Contents of this chapter

This chapter contains the telegram and response structures for I&M (Identification & Maintenance) records.

I&M records

I&M records can be read, for example, with the DTM tool. The FPBA-01 module supports the mandatory I&M0 record as well as the optional I&M1 and I&M2 records.

■ **Call-REQ-PDU telegram for read/write access to I&M records**

	Contents	Size	Coding	Notes
DP-V1 header	Function_Num	1 Octet	5Fh	fixed
	Slot_Number	1 Octet	0...255	variable
	Index	1 Octet	255	fixed
	Length	1 Octet	4 / 68	Call Header only / Write
Call Header	Extended_Function_Num	1 Octet	08h	Indicates “Call”, fixed
	reserved	1 Octet	00h	fixed
	FI_Index	2 Octets	65000 ...	Subindex of I&M0 Record 65000 = I&M0 65001 = I&M1 65002 = I&M2
	IM_Function	64 Octets	Data	Write only (I&M1 or I&M2)

■ Response structure for I&M0 (Read-only)

	Contents	Size	Coding
Header	Manufacturer-specific	10 Octets	“FPBA-01”
I&M block	MANUFACTURER_ID	2 Octets	0x1A = ABB Automation
	ORDER_ID	20 Octets	“68469325” (for FPBA-01 kit)
	SERIAL_NUMBER	16 Octets	Serial number of FPBA module
	HARDWARE_REVISION	2 Octets	Hardware version of FPBA module
	SOFTWARE_REVISION	4 Octets	Format: V255.255.255 E.g., V1.0.0 = software version 1.00
	REVISION_COUNTER	2 Octets	(Marks a change of hardware or its parameters)
	PROFILE_ID	2 Octets	3A00 (...3AFF) PROFIdrive
	PROFILE_SPECIFIC_TYPE	2 Octets	0 = no specific type
	IM_VERSION	2 Octets	0x0101 = version 1.1
	IM_SUPPORTED	2 Octets	3 = I&M0, I&M1 and I&M2 supported

■ **Response structure for I&M1 (Read/Write)**

	Contents	Size	Coding
Header	Manufacturer-specific	10 Octets	–
I&M0 block	TAG_FUNCTION	32 Octets	Device function or task
	TAG_LOCATION	22 Octets	Device location

■ **Response structure for I&M2 (Read/Write)**

	Contents	Size	Coding
Header	Manufacturer-specific	10 Octets	–
I&M0 block	INSTALLATION_DATE	16 Octets	Installation date. E.g., 2011-01-01 16:23
	RESERVED	38 Octets	Reserved

Note: I&M1 and I&M2 are blank (0x20) by default.

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals


Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives



3AFE68573271H